
ABB INDUSTRIAL DRIVES

ACS880-107LC inverter units

Hardware manual



ACS880-107LC inverter units

Hardware manual

Table of contents



3. Electrical installation



5. Start-up



Table of contents

1 Introduction to the manual

Contents of this chapter	11
Applicability	11
Safety instructions	11
Target audience	11
Categorization by frame size and option code	12
Use of component designations	13
Related documents	13
Terms and abbreviations	14

2 Operation principle and hardware description

Contents of this chapter	15
Overview diagram of the drive system	16
Inverter unit hardware	16
General	16
Inverter module hardware	17
Frame R8i and multiples	17
BCU control unit of frame R8i and multiples	17
Module layout	18
Coolant connectors	18
Connectors X50...X59	19
Fiber optic connectors	20
Cooling system	20
Control interfaces	21
Overview of the control connections of the BCU control unit	21
The ACx-AP-x control panel	21
Control by PC tools	22
Type designation labels	23
Inverter unit type designation label	23
Inverter module type designation label	23
Inverter unit type designation key	23

3 Electrical installation

Contents of this chapter	27
Electrical safety precautions	27
General notes	29
Printed circuit boards	29
Optical components	29
Checking the insulation of the assembly	29
Inverter unit	29
Checking the insulation of the motor and motor cable	29
Connecting the control cables	30
Control cable connection procedure	30
Grounding the outer shields of the control cables at the cabinet entry	30
Routing the control cables inside the cabinet	32



Connecting control cabling	32
Connecting the motor cables (units without common motor terminal cubicle or sine output filter)	34
Motor connection diagram (without option +H366)	34
Motor connection diagram (with option +H366)	35
Procedure	35
Connecting the motor cables (units with common motor terminal cubicle or sine output filter)	39
Output busbars	39
Connection diagram	39
Procedure	39
Connecting a PC	41
Panel bus (Control of several units from one control panel)	42
Installing option modules	44
Mechanical installation of I/O extension, fieldbus adapter and pulse encoder interface modules	44
Installation of an FSO-xx safety functions module onto BCU	44
Wiring of optional modules	46
4 Installation checklist of the drive	
Contents of this chapter	47
Checklist	47
5 Start-up	
Contents of this chapter	49
Start-up procedure	49
6 Maintenance	
Contents of this chapter	53
Maintenance intervals	53
Retightening the power connections	54
Fans	55
Inverter module fan replacement	55
Replacing the common motor terminal cubicle fan	56
Inverter modules	57
Replacing a frame R8i inverter module	57
Removing the module	59
Reinstalling the module	61
Capacitors	61
Reforming the capacitors	61
DC fuse replacement	62
Control panel	64
Cleaning the control panel	64
Replacing the control panel battery	64
Control units	65
BCU control unit types	65
Replacing the memory unit	65
Replacing the BCU control unit battery	65
7 Control units of the drive	
Contents of this chapter	67



General	67
BCU-x2 control unit layout and connections	68
Default I/O diagram of the inverter control unit (A41)	70
External power supply for the control unit (XPOW)	71
DI6 as a PTC sensor input	71
AI1 or AI2 as a Pt100, Pt1000, PTC or KTY84 sensor input	72
DIIL input	72
The XD2D connector	72
Safe torque off (XSTO, XSTO OUT)	73
FSO-xx safety functions module connection (X12)	73
SDHC memory card slot	73
Connector data	74
BCU-x2 ground isolation diagram	76
8 The Safe torque off function	
Contents of this chapter	77
Description	77
Compliance with the European Machinery Directive	78
Wiring	79
Activation switch	79
Cable types and lengths	79
Grounding of protective shields	79
Dual-channel connection with internal power supply	80
Frame R8i and multiples	80
Single-channel connection of activation switch	81
Multiple drives	82
Internal power supply	82
External power supply	83
Operation principle	84
Start-up including acceptance test	85
Competence	85
Acceptance test reports	85
Acceptance test procedure	85
Use	87
Maintenance	88
Competence	88
Fault tracing	89
Safety data	90
Abbreviations	91
TÜV certificate	91
9 Internal cooling circuit	
Contents of this chapter	93
Applicability	93
Internal cooling system	93
Connection to a cooling unit	95
Connection to an ACS880-1007LC cooling unit	95
Connection to a custom cooling unit	95
General requirements	95
Coolant temperature control	95



Filling up and bleeding the internal cooling circuit	96
Drive line-ups with an ACS880-1007LC cooling unit	96
Drive line-ups with a custom cooling unit	96
Draining the internal cooling circuit	98
Maintenance intervals	98
Technical data	98
Coolant specification	98
Coolant type	98
Temperature limits	98
Pressure limits	100
Coolant flow rate limits	100
Cooling circuit materials	100

10 Technical data

Contents of this chapter	103
Ratings	104
Definitions	104
Derating	105
Ambient temperature derating	105
Coolant temperature derating	105
Antifreeze content derating	105
Altitude derating	105
Switching frequency derating	105
Output frequency derating	106
Inverter unit frame sizes and modules used	106
Cooling data and noise	107
DC fuses	108
Dimensions and weights	108
Free space requirements	108
Typical power cable sizes	110
Terminal and cable entry data for power cables	112
Terminal data for the inverter control unit	112
Input power (DC) connection	112
Motor (AC) connection	112
Efficiency	112
Protection classes	113
Optical components	113
Ambient conditions	114
Materials	115
Applicable standards	115
Markings	115
Tightening torques	115
Electrical connections	116
Mechanical connections	116
Insulation supports	116
Cable lugs	116
Disclaimers	117
Generic disclaimer	117
Cybersecurity disclaimer	117




11 Dimensions

Cabinet line-up dimensions	119
Dimensions and weights	120
Dimension drawing examples	121
Cabinet height and depth	121
Location and size of output terminals	122
Units without common motor terminal cubicle	122
Inverter module cubicle with one R8i module, bottom cable exit	122
Inverter module cubicle with two R8i modules, bottom cable exit	123
Inverter module cubicle with three R8i modules, bottom cable exit	124
Units with common motor terminal cubicle (+H359)	125
Cubicle width 300 mm, bottom cable exit	125
Cubicle width 300 mm, top cable exit	126
Cubicle width 400 mm, bottom cable exit	127
Cubicle width 400 mm, top cable exit	128
Cubicle width 600 mm, bottom cable exit	129
Cubicle width 600 mm, top cable exit	130

Further information





1

Introduction to the manual

Contents of this chapter

This chapter gives basic information on the manual.

Applicability

This manual is applicable to ACS880-107LC inverter units that form a part of a drive system.

Safety instructions

Follow all safety instructions delivered with the drive.

- Read the **complete safety instructions** before you install, commission, use or service the drive. The complete safety instructions are given in *ACS880 liquid-cooled multidrive cabinets and modules safety instructions* (3AXD50000048633 [English]).
- Read the **software-function-specific warnings and notes** before changing the default settings of a function. For each function, the warnings and notes are given in the section describing the related user-adjustable parameters.
- Read the **task-specific safety instructions** before starting the task. See the section describing the task.

Target audience

This manual is intended for people who plan the installation, install, start up and service the drive, or create instructions for the end user of the drive concerning the installation and maintenance of the drive.

Read the manual before working on the drive. You are expected to know the fundamentals of electricity, wiring, electrical components and electrical schematic symbols.

The manual is written for readers worldwide. Both SI and imperial units are shown.

Categorization by frame size and option code

Some descriptions, instructions, technical data and other information that concern only a certain group of units may be marked with the frame size (such as "R8i", "4×R8i", etc.) The marking derives from the quantity and basic construction of the modules that form the unit. For example, the frame size "2×R8i" indicates that the unit consists of two frame size R8i modules connected in parallel.

The frame size is marked on the type designation labels. The frame size of each unit is also shown in the rating tables in chapter *Technical data*.

The information that concerns only certain optional selections is marked with option codes (such as +E205). The options included in the unit can be identified from the type code visible on the type designation label. The option selections are listed in section *Inverter unit type designation key (page 23)*.

Use of component designations

Some device names in the manual include the item designation in brackets, for example [Q20], to make it possible to identify the components in the circuit diagrams of the drive.

Related documents

Manual	Code
General manuals	
<i>ACS880 liquid-cooled multidrive cabinets and modules safety instructions</i>	3AXD50000048633
<i>ACS880 liquid-cooled multidrive cabinets and modules electrical planning instructions</i>	3AXD50000048634
<i>ACS880 liquid-cooled multidrive cabinets mechanical installation instructions</i>	3AXD50000048635
<i>CIO-01 I/O module for distributed I/O bus control user's manual</i>	3AXD50000126880
Supply unit manuals	
<i>ACS880-207LC IGBT supply units hardware manual</i>	3AXD50000174782
<i>ACS880 IGBT supply control program firmware manual</i>	3AUA0000131562
Inverter unit manuals	
<i>ACS880-107LC inverter units hardware manual</i>	3AXD50000196111
<i>ACS880 primary control program firmware manual</i>	3AUA0000085967
<i>ACS880 primary control program quick start-up guide</i>	3AUA0000098062
Manuals for application programs (Crane, Winder, etc.)	
Brake unit and DC/DC converter unit manuals	
<i>ACS880-607LC 1-phase brake units hardware manual</i>	3AXD50000481491
<i>ACS880 (3-phase) brake control program firmware manual</i>	3AXD50000020967
<i>ACS880-1607LC DC/DC converter units hardware manual</i>	3AXD50000431342
<i>ACS880 DC/DC converter control program firmware manual</i>	3AXD50000024671
Option manuals	
<i>ACS880-1007LC liquid cooling unit user's manual</i>	3AXD50000129607
<i>ACS-AP-x assistant control panels user's manual</i>	3AUA0000085685
<i>Drive composer start-up and maintenance PC tool user's manual</i>	3AUA0000094606
Manuals for I/O extension modules, fieldbus adapters, safety options etc.	

You can find manuals on the Internet. See www.abb.com/drives/documents. For manuals not available in the document library, contact your local ABB representative.

Terms and abbreviations

Term	Description
BCU	Type of control unit
CIO	I/O module for controlling cabinet fans
Drive	Frequency converter for controlling AC motors
EMC	Electromagnetic compatibility
EMI	Electromagnetic interference
FEN-01	Optional TTL incremental encoder interface module
FEN-11	Optional TTL absolute encoder interface module
FEN-21	Optional resolver interface module
FEN-31	Optional HTL incremental encoder interface module
FIO-11	Optional analog I/O extension module
FPTC-01	Optional thermistor protection module
FPTC-02	Optional ATEX-certified thermistor protection module for potentially explosive atmospheres
Frame, frame size	Physical size of the drive or power module
FSO-12, FSO-21	Optional functional safety modules
IGBT	Insulated gate bipolar transistor
Inverter unit	Inverter module(s) under control of one control board, and related components. One inverter unit typically controls one motor.
Power module	Common term for drive module, inverter module, supply module, brake chopper module etc.
RFI	Radio-frequency interference
STO	Safe torque off (IEC/EN 61800-5-2)
Supply unit	Supply module(s) under control of one control board, and related components.



2


Operation principle and hardware description

Contents of this chapter

This chapter describes a typical drive system and the hardware of the inverter unit.

Overview diagram of the drive system

The diagram below depicts a common DC bus drive system.



The supply unit connects to the AC supply network and converts the AC voltage into DC. The DC voltage is distributed through the DC bus to all inverter units. The inverter unit, consisting of one or more inverter modules, converts the DC back to AC that rotates the motor.

The inverter units can be used for controlling asynchronous AC induction motors, permanent magnet synchronous motors, AC induction servomotors and ABB synchronous reluctance (SynRM) motors

Inverter unit hardware

■ General

An inverter unit contains the components required to control one motor. These include one or more inverter modules connected in parallel, together with the necessary auxiliary equipment such as control electronics, fusing, cabling and switchgear.

ACS880-107LC inverter units range from 355 to 6000 kW in power. The units employ ACS880-104LC (frame R8i) modules. Up to approximately 800 kW, inverter units consist of one module only; higher power ratings are achieved by connecting multiple modules in parallel.

All inverter modules have coated circuit boards as standard.

Inverter module hardware

■ Frame R8i and multiples

Frame R8i modules are used to achieve output powers from approximately 350 kW upwards in single or parallel configurations.


The DC connection of the module is by busbars and located at the top. The motor connection is via a quick connector at the back of the module that couples when the module is inserted into the cubicle. Each parallel-connected module is cabled separately to the motor, or connected by busbars to adjacent modules to reduce the number of cables. It is also possible to build an AC bus from each module to a separate output cubicle.

Internal du/dt filtering is mandatory with all 690 volt units and all parallel-connected modules. 690 volt modules have internal du/dt filtering as standard.

BCU control unit of frame R8i and multiples

Inverter units consisting of one or several R8i modules employ a separate control unit (BCU) that contains the BCON board with basic I/Os and slots for optional I/O modules. A fiber optic link connects the BCU to each inverter module. Any safety circuits utilizing the built-in Safe torque off functionality are connected to the BCU. The forwarding connector of the BCU is wired to the inverter module(s).

Module layout



No.	Description
1.	DC input busbars
2.	Lifting eyes, front (a) and back (b)
3.	Coolant in (a) and out (b) connectors. See section Coolant connectors .
4.	Handle
5.	Fiber optic connectors. See section Fiber optic connectors .
6.	Quick connector (AC output) (the counterpart fastened to the cabinet behind the module)
7.	Terminal block X50 (auxiliary power input for internal boards). See section Connectors X50...X59 .
8.	Terminal block X51 and X52 (Safe torque off). See section Connectors X50...X59 .
9.	Terminal block X53 (24 V DC power output). See section Connectors X50...X59 .
10.	Auxiliary voltage selector (115 or 230 V). See section Connectors X50...X59 .
11.	Unpainted fastening hole. The grounding point (PE) between module frame and cabinet frame.

Coolant connectors

The coolant pipe inlet and outlet connectors are located at the bottom front of the module. The connectors are for 16/13 millimeter PA (polyamide) pipe.



WARNING!

For a reliable connection, the end of the pipe entering the connector must be completely intact for a length of at least 5 cm (2"). Make sure the pipe is perfectly round where it enters the connector, and not deformed eg. by any bends nearby. The piping must not exert any tension or torque on the connector.

Connectors X50...X59

R8i modules contain a power supply (BDPS) that provides 24 V DC for the circuit boards of the module. The 24 V DC voltage provided by the BDPS is also available on X53, and can be used to power the BCU control unit of a single R8i inverter module.

Note:

With an inverter unit consisting of parallel-connected R8i modules, it is strongly recommended to use an external 24 V DC supply to power the BCU control unit.


The BDPS is powered internally from the DC link. An auxiliary voltage of 230 V AC or 115 V AC (selectable) can optionally be fed to terminal block X50 to power the BDPS even when the DC link is not live. The selection between 115 V and 230 V is made with selector plug X59. The setting can be changed by removing the two screws, turning the plug 180 degrees, and reinstalling the screws.

If the Safe torque off (STO) function is not used, the "24V" inputs on X52 must be connected to +24 V (on connector X53, for example) on each inverter module. On a new module, a jumper wire set installed at the factory makes this connection.

If the STO function is to be implemented, the jumper wire set must be removed – a mechanical interlocking device is factory-installed on connectors X51 and X52 to this effect.

For STO, X52 (STO IN) is wired to the STO OUT connector on the BCU control unit. Connector X51 on the module is wired to connector X52 on the next module (if present). For details, see chapter The Safe torque off function.

20 Operation principle and hardware description



Fiber optic connectors

BSFC	V50←		Name	Description
	V60→		BSFC	Reserved.
BCU	V10←		BCU	Control unit connection. Must be connected by the installer.
	V20→			


Cooling system

See chapter [Internal cooling circuit \(page 93\)](#).

Control interfaces

■ Overview of the control connections of the BCU control unit

The diagram shows the control connections and interfaces of the BCU control unit.



■ The ACx-AP-x control panel

The ACx-AP-x control panel is the user interface of the inverter unit, providing the essential controls such as Start/Stop/Direction/Reset/Reference, and the parameter settings for the control program.

22 Operation principle and hardware description

One control panel can be used to control several inverter units through a panel link provided that each unit is equipped with panel holder or an FDPI-02 module.

Note:

A control panel is required for the commissioning of an ACS880 drive system, even if the Drive composer PC tool is used.

For details on the control panel, see *ACX-AP-x Assistant control panels User's manual* (3AUA0000085685 [English]).

Control by PC tools

There is a USB connector on the front of the panel that can be used to connect a PC to the drive. When a PC is connected to the control panel, the control panel keypad is disabled.

For more information see section Connecting a PC.

Type designation labels

■ Inverter unit type designation label

Each inverter unit has a type designation label attached onto the inside of the cubicle door. Note that an inverter unit may consist of several cubicles and inverter modules.

The type designation stated on the label contains information on the specifications and configuration of the unit. The first digits express the basic construction of the unit, for example “ACS880-107LC-0600A-7”. Any optional selections are given thereafter, separated by plus signs.

Quote the complete type designation and serial number when contacting technical support on the subject of individual inverter modules. An example of the label is shown below.

 MADE IN FINLAND ABB Oy Himontie 13 00380 Helsinki Finland	ACS880-107LC-1470A-7+A012+B054+E205+E210+ G300+G301+G307+G313+G315+G320+H352+H359+ H367+K450+K454+L500+L509+N8010+Q951	   S/N: 1171705096
FRAME 2xR8i	Input U1 742/849/976 VDC I1 1654 A f1 -	
Liquid cooling IP42	Output U2 3~ 0...525/600/690 VAC I2 1470 A f2 0...500 Hz Sn 1757 kVA	
UL/CSA: max. 849 VDC/600 VAC		

No.	Description
1	Type designation (see Inverter unit type designation key)
2	Frame size
3	Cooling method, degree of protection, additional UL/CSA specifications
4	Ratings (see also section Ratings (page 104))
5	Valid markings. See Electrical planning instructions for ACS880 multidrive cabinets and modules (3AUA0000102324 [English]) .
6	Serial number. The first digit of the serial number refers to the manufacturing plant. The next four digits refer to the unit's manufacturing year and week respectively. The remaining digits complete the serial number so that there are no two units with the same number.

■ Inverter module type designation label

Each inverter module has a type designation label attached to it. The type designation stated on the label contains information on the specifications and configuration of the unit. The first digits express the basic construction of the unit, for example “ACS880-104LC-0850A-7”. Any optional selections are given thereafter, separated by plus signs.

Quote the complete type designation and serial number when contacting technical support on the subject of individual inverter modules.

Inverter unit type designation key

The type designation contains information on the specifications and configuration of the unit. The first digits from left express the basic configuration (for example, ACS880-107LC-0850A-7). The optional selections are given thereafter, separated by plus signs. The main selections are described below. Not all selections are available for all types. For more information, refer to [ACS880 multidrive ordering information](#), available on request.

24 Operation principle and hardware description

Code	Description
Basic code	
ACS880	Product series
ACS880-107LC	Default configuration: liquid-cooled cabinet-installed drive, IP42 (UL Type 1), ACS-AP-W assistant control panel (with Bluetooth), du/dt filters, common mode filtering, ACS880 primary control program, Safe torque off function, coated circuit boards, bottom entry and exit of cables, USB memory stick containing circuit diagrams, dimension drawings and manuals.
Size	
xxxxx	Refer to the rating tables
Voltage range	
7	525...690 V AC. This is indicated in the type designation label as typical input voltage levels (3~ 525/600/690 V AC)
Option codes (plus codes)	
Supply connection	
Degree of protection	
B054	IP42 (UL Type 1)
Construction	
C121	Marine construction.
C128	Air inlet through bottom of cabinet.
Filters	
E208	Common mode filtering
Switching and grounding	
F286	DC switch/disconnector
Cabinet equipment	
G300	Cabinet and module heating elements (external supply).
G301	Cabinet lighting.
G304	Control (auxiliary) voltage 115 V AC
G313	Output for motor space heater (external supply)
G327	Ready light on door, white
G328	Run light on door, green
G329	Fault light on door, red
G330	Halogen-free wiring and materials
G338	Additional wire markings.
G339	
G340	
G341	
G342	
G342	
Cabling	
H350	Supply cabling direction down
H351	Supply cabling direction up
H353	Motor cabling direction up
H359	Common motor terminal cubicle.
H366	Common output terminals (for inverter modules mounted in the same cubicle).
Control panel	
J400	ACS-AP-W control panel (with Bluetooth)

Code	Description
J401	LED monitoring display
J410	Control panel mounting platform (max. 4 per door)
Fieldbus adapters, diverse communication options	
K450	Panel bus (control of several units from one control panel)
K451	FDNA-01 DeviceNet™ adapter module
K452	FLON-01 LonWorks® adapter module
K454	FPBA-01 PROFIBUS DP adapter module
K457	FCAN-01 CANopen adapter module
K458	FSCA-01 RS-485 (Modbus/RTU) adapter module
K462	FCNA-01 ControlNet™ adapter module
K469	FECA-01 EtherCat adapter module
K470	FEPL-02 EtherPOWERLINK adapter module
K473	FENA-11 Ethernet adapter module for EtherNet/IP™, Modbus TCP and PROFINET IO protocols
K475	FENA-21 Ethernet adapter module for EtherNet/IP™, Modbus TCP and PROFINET IO protocols, 2-port
K480	Ethernet switch for PC tool or control network (for max. 6 inverter units)
K483	Ethernet switch with optical link for PC tool or control network (for max. 6 inverter units)
I/O extensions and feedback interfaces	
L500	FIO-11 analog I/O extension module (1, 2 or 3 pcs)
L501	FIO-01 digital I/O extension module (1, 2 or 3 pcs)
L502	FEN-31 HTL incremental encoder interface module
L503	FDCO-01 optical DDCS communication adapter module
L504	Additional I/O terminal block.
L505	Thermal protection with PTC relays (1 or 2 pcs).
L506	Thermal protection with Pt100 relays (2, 3, 5 or 8 pcs).
L508	FDCO-02 optical DDCS communication adapter module
L513	ATEX-certified thermal protection with PTC relays (1 or 2 pcs)
L514	ATEX-certified thermal protection with Pt100 relays (3, 5 or 8 pcs)
L515	FEA-03 I/O extension adapter
L516	FEN-21 resolver interface module
L517	FEN-01 TTL incremental encoder interface module
L518	FEN-11 TTL absolute encoder interface module
L521	FSE-31 pulse encoder interface module
L525	FAIO-01 analog I/O extension module
L526	FDIO-01 digital I/O extension module
L536	FPTC-01 thermistor protection module
L537	FPTC-02 ATEX-certified thermistor protection module
Starter for auxiliary motor fan	
4	Trip limit setting range: 1.6 ... 2.5 A
M602	Trip limit setting range: 2.5 ... 4 A
M603	Trip limit setting range: 4 ... 6.3 A
M604	Trip limit setting range: 6.3 ... 10 A
M605	Trip limit setting range: 10...16 A

26 Operation principle and hardware description

Code	Description
M606	Trip limit setting range: 16...20 A
M610	Trip limit setting range: 20...25 A
Control program	
N5000	Winder control program
N5050	Crane control program
N5100	Winch control program
N5200	PCP (Progressive Cavity Pump) control program
N5300	Test bench control program
N5450	Override control program
N5600	ESP (Electrical Submersible Pump) control program
N7502	Control program for synchronous reluctance motors (SynRM)
N8010	IEC 61131-3 application programmability
Specialties	
P902	Customized
P904	Extended warranty
P912	Seaworthy packaging
P913	Special color
P929	Container packaging
Safety functions	
Q965	Safely-limited speed with FSO-21 and encoder
Q966	Safely-limited speed without encoder
Q971	ATEX-certified safe disconnection function
Q972	FSO-21 safety functions module
Q973	FSO-12 safety functions module
Q982	PROFIsafe with FSO-xx safety functions module and FENA-21 Ethernet adapter module
Full set of printed manuals in the selected language	
Note:	
The delivery may include manuals in English if the requested language is not available.	
R700	English
R701	German
R702	Italian
R703	Dutch
R704	Danish
R705	Swedish
R706	Finnish
R707	French
R708	Spanish
R709	Portuguese
R711	Russian
R715	Complete documentation, user manuals in memory stick
R716	Hard copies of documentation
R717	Second set of hard copies of documentation

3

Electrical installation

Contents of this chapter

This chapter gives instructions on the wiring of the drive.

Electrical safety precautions

These electrical safety precautions are for all personnel who do work on the drive, motor cable or motor.

**WARNING!**

Obey these instructions. If you ignore them, injury or death, or damage to the equipment can occur.

If you are not a qualified electrician, do not do installation or maintenance work.

Go through these steps before you begin any installation or maintenance work.

-
1. Keep the cabinet doors closed when the drive is powered. With the doors open, a risk of a potentially fatal electric shock, arc flash or high-energy arc blast exists.
 2. Clearly identify the work location and equipment.
 3. Disconnect all possible voltage sources. Lock out and tag out.
 - Open the main disconnecting device of the drive.
 - Open the charging switch if present.
 - Open the disconnecter of the supply transformer. (The main disconnecting device in the drive cabinet does not disconnect the voltage from the AC input power busbars of the drive cabinet.)
 - If the drive is equipped with a DC/DC converter unit (optional): Open the DC switch/disconnector ([Q11], option +F286) of the DC/DC converter. Open the disconnecting device of the energy storage connected to the DC/DC converter unit (outside the drive cabinet).
-



- Open the auxiliary voltage switch-disconnector (if present), and all other possible disconnecting devices that isolate the drive from dangerous voltage sources.
 - In the liquid cooling unit (if present), open the motor protective circuit breaker(s) of the cooling pumps.
 - If you have a permanent magnet motor connected to the drive, disconnect the motor from the drive with a safety switch or by other means.
 - Make sure that re-connection is not possible. Lock out and tag out.
 - Disconnect any dangerous external voltages from the control circuits.
 - After you disconnect power from the drive, always wait 5 minutes to let the intermediate circuit capacitors discharge before you continue.
4. Protect any other energized parts in the work location against contact.
 5. Take special precautions when close to bare conductors.
 6. Measure that the installation is de-energized. If the measurement requires removal or disassembly of shrouding or other cabinet structures, obey the local laws and regulations applicable to live working (including – but not limited to – electric shock and arc protection).
 - Use a multimeter with an impedance greater than 1 Mohm.
 - Make sure that the voltage between the drive input power terminals (L1, L2, L3) and the grounding (PE) busbar is close to 0 V.
 - Make sure that the voltage between the drive DC busbars (+ and -) and the grounding (PE) busbar is close to 0 V.
 - If you have a permanent magnet motor connected to the drive, make sure that the voltage between the drive output terminals (T1/U, T2/V, T3/W) and the grounding (PE) busbar is close to 0 V.



WARNING!

The busbars inside the cabinet are partially coated. Measurements made through the coating are potentially unreliable, so only measure at uncoated portions. Note that the coating does not constitute a safe or touch-proof insulation.

7. Install temporary grounding as required by the local regulations.
8. Ask the person in control of the electrical installation work for a permit to work.

General notes

■ Printed circuit boards



WARNING!

Use a grounding wrist band when you handle printed circuit boards. Do not touch the boards unnecessarily. The boards contain components sensitive to electrostatic discharge.

■ Optical components



WARNING!

Obey these instructions. If you ignore them, damage to the equipment can occur.

- Handle the fiber optic cables with care.
- When you unplug the fiber optic cables, always hold the connector, not the cable itself.
- Do not touch the ends of the fibers with bare hands as the ends are extremely sensitive to dirt.
- Do not bend the fiber optic cables too tightly. The minimum allowed bend radius is 35 mm (1.4”).

Checking the insulation of the assembly

■ Inverter unit



WARNING!

Do not make any voltage withstand or insulation resistance tests on any part of the drive as testing can damage the drive. Every drive has been tested for insulation between the main circuit and the chassis at the factory. Also, there are voltage-limiting circuits inside the drive which cut down the testing voltage automatically.

■ Checking the insulation of the motor and motor cable



WARNING!


Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

If you are not a qualified electrician, do not do installation or maintenance work.

1. Stop the drive and do the steps in section *Electrical safety precautions (page 27)* before you start the work.
2. Check that the motor cable is disconnected from the drive output terminals.
3. Measure the insulation resistance between the phase conductors and then between each phase conductor and the Protective Earth conductor. Use a measuring voltage of 1000 V DC. The insulation resistance of an ABB motor must exceed 100 Mohm (reference value at 25 °C [77 °F]). For the insulation resistance of other motors, consult the manufacturer's instructions.

Note:

Moisture inside the motor casing reduces the insulation resistance. If moisture is suspected, dry the motor and repeat the measurement.



Connecting the control cables

See the chapter on control units for the default I/O connections. Note that the default I/O connections can be affected by some options. See the circuit diagrams delivered with the drive for the actual wiring.

■ Control cable connection procedure

**WARNING!**

Obey the safety instructions given in *Safety instructions for ACS880 liquid-cooled multidrive cabinets and modules (3AXD50000048633 [English])*. If you ignore the safety instructions, injury or death, or damage to the equipment can occur.


If you are not a qualified electrician, do not do installation or maintenance work.

1. Stop the drive (if running) and do the steps in section [Electrical safety precautions \(page 27\)](#) before you start the work.
2. Run the control cables into the cabinet as described in section [Grounding the outer shields of the control cables at the cabinet entry](#) below.
3. Route the control cables as described in section [Routing the control cables inside the cabinet](#).
4. Connect the control cables as described in section [Connecting control cabling](#).

Grounding the outer shields of the control cables at the cabinet entry

Ground the outer shields of all control cables 360 degrees at the EMI conductive cushions as follows (example constructions are shown below, the actual hardware may vary):


1. Loosen the tightening screws of the EMI conductive cushions and pull the cushions apart.
2. Cut adequate holes to the rubber grommets in the entry plate and put the cables through the grommets and the cushions.
3. Strip off the cable plastic sheath above the entry plate just enough to ensure proper connection of the bare shield and the EMI conductive cushions.
4. Tighten the two tightening screws so that the EMI conductive cushions press tightly round the bare shield.



Note 1: Keep the shields continuous as close to the connection terminals as possible. Secure the cables mechanically at the entry strain relief.

Note 2: If the outer surface of the shield is non-conductive:

- Cut the shield at the midpoint of the bare part. Be careful not to cut the conductors or the grounding wire (if present).
- Turn the shield inside out to expose its conductive surface.
- Cover the turned shield and the stripped cable with copper foil to keep the shielding continuous.




Note for top entry of cables: When each cable has its own rubber grommet, sufficient IP and EMC protection can be achieved. However, if very many control cables come to one cabinet, plan the installation beforehand as follows:

1. Make a list of the cables coming to the cabinet.
2. Sort the cables going to the left into one group and the cables going to the right into another group to avoid unnecessary crossing of cables inside the cabinet.
3. Sort the cables in each group according to size.
4. Group the cables for each grommet as follows ensuring that each cable has a proper contact to the cushions on both sides.

Cable diameter in mm	Max. number of cables per grommet
≤ 13	4
≤ 17	3
< 25	2
≥ 25	1

5. Arrange the bunches according to size from thickest to the thinnest between the EMI conductive cushions.



6. If more than one cable go through a grommet, seal the grommet by applying Loctite 5221 (catalogue number 25551) inside the grommet.

Routing the control cables inside the cabinet

Use the existing trunking in the cabinet wherever possible. Use sleeving if cables are laid against sharp edges. When running cables to or from a swing-out frame, leave enough slack at the hinge to allow the frame to open fully.

Connecting control cabling

Connect the conductors to the appropriate terminals. Refer to the wiring diagrams delivered with the drive.

With option +L504, the terminals of the inverter control unit are available on terminal block X504.


Connect the inner twisted pair shields and all separate grounding wires to the grounding clamps closest to the terminals.

The drawing below represents the grounding of the control cabling when connecting to a terminal block inside the cabinet. The grounding is done in the same way when connecting directly to a component such as the control unit.

Notes:

- Do not ground the outer shield of the cable here since it is grounded at the lead-through.
- Keep any signal wire pairs twisted as close to the terminals as possible. Twisting the wire with its return wire reduces disturbances caused by inductive coupling.





At the other end of the cable, leave the shields unconnected or ground them indirectly via a high-frequency capacitor with a few nanofarads, eg. 3.3 nF / 630 V. The shield can also be grounded directly at both ends if they are in the same ground line with no significant voltage drop between the end points.



Connecting the motor cables (units without common motor terminal cubicle or sine output filter)

On units without a common motor terminal cubicle or a sine output filter, the motor cables connect to busbars located in the inverter module cubicles. To access the terminals, the cooling fans and other equipment in front of the terminals must be removed from the cubicle.


The location and dimensions of the busbars are visible in the dimension drawings delivered with the drive, as well as the example drawings presented in this manual in chapter *Dimensions*.

If the drive is equipped with a common motor terminal cubicle (option +H359) or a sine output filter (option +E206), follow the instructions in section [Connecting the motor cables \(units with common motor terminal cubicle or sine output filter\)](#) (page 39).

■ Motor connection diagram (without option +H366)

All parallel-connected inverter modules are to be cabled separately to the motor.

360° earthing is to be used at cable lead-throughs.




The recommended cable types are given in chapter *Technical data*.




WARNING!

The cabling from all inverter modules to the motor must be physically identical considering cable type, cross-sectional area, and length.



■ Motor connection diagram (with option +H366)

With option +H366, the output busbars of the inverter modules **within the same cubicle** are connected by bridging busbars. The bridging balances the motor current between the modules, which allows more cabling options. For example, it is possible to use a number of cables that could not otherwise be evenly distributed between the inverter modules.



The recommended cable types are given in chapter *Technical data*.



WARNING!

The bridging can carry the nominal output of one inverter module. In case of three parallel modules, ensure that the load capacity of the bridging is not exceeded. For example, if the cabling connects to the output busbars at one module only, use the module in the middle.

Note:

The +H366 option only interconnects the outputs of inverter modules within the same cubicle, not modules installed in different cubicles. Therefore, when the drive has more than three inverter modules, make sure that the load is distributed evenly between the modules:

- In case of two inverter cubicles of two modules, connect the same number of cables to each cubicle.
- In case of one inverter cubicle with three modules and another with two, each cubicle requires a number of cables proportional to the number of modules within. For example, connect three out of five (or six out of ten, etc.) cables to the cubicle with three modules, the remaining two out of five (four out of ten) cables to the cubicle with two modules.

■ Procedure

Refer to the drawings below.



WARNING!

Obey the instructions in *Safety instructions for ACS880 liquid-cooled multidrive cabinets and modules* (3AXD50000048633 [English]). If you ignore them, injury or death, or damage to the equipment can occur.

1. Do the steps in section *Electrical safety precautions (page 27)* before you start the work.

2. Open the inverter module cubicle door.
3. Remove the shrouding at the lower part of the cubicle (not shown).
4. Unplug the wiring from the lower front mounting plate. Remove the plate.
5. Disconnect the wiring from the cooling fans.
6. Undo the two retaining screws (a) of each fan.
7. Pull each fan outwards to separate them from the heat exchanger housing.
8. Remove the inner shroud.
9. Peel off 3 to 5 cm of the outer insulation of the cables above the lead-through plate for 360° high-frequency grounding.
10. Prepare the ends of the cables.







WARNING!

Apply grease to stripped aluminum conductors before attaching them to non-coated aluminum cable lugs. Obey the grease manufacturer's instructions. Aluminum-aluminum contact can cause oxidation in the contact surfaces.

11. If fire insulation is used, make an opening in the mineral wool sheet according to the diameter of the cable.
12. Remove the rubber grommets from the cable entries for the cables to be connected. Cut adequate holes into the rubber grommets. Slide the grommets onto the cables. Slide the cables into the cubicle through the conductive sleeves and attach the grommets to the holes.
13. Attach the conductive sleeves to the cable shields with cable ties. Tie up the unused conductive sleeves with cable ties.
14. Seal the gap between the cable and mineral wool sheet (if used) with sealing compound (eg. CSD-F, ABB brand name DXXT-11, code 35080082).
15. Connect the twisted shields of the cables to the PE busbar of the cabinet.
16. Connect the phase conductors of the cables to the appropriate terminals. Tighten the screws to the torque given under *Tightening torques (page 115)*.
17. Refit the inner shroud.
18. With each fan, align the guide pins (b) at the rear of the fan cowling with the slots (c) in the module bottom guide, then reinstall the retaining screws (a).
19. Refit the lower front mounting plate. Reconnect the wiring to the components on the mounting plate.
20. Refit the outer shroud.
21. Make sure there are no tools, debris or any other foreign objects in the cubicle. Close the cubicle door.
22. At the motor, connect the cables according to instructions from the motor manufacturer. Pay special attention to the phase order. For minimum radio-frequency interference, ground the cable shield 360 degrees at the cable entry of the motor terminal box, or ground the cable by twisting the shield so that the flattened shield is wider than 1/5 of its length.








Connecting the motor cables (units with common motor terminal cubicle or sine output filter)

■ Output busbars

If the drive is equipped with option +H359, the motor cables connect to a common motor terminal cubicle. Similarly, if the drive is equipped with option +E206 (sine output filter), the motor cables connect to the output busbars in the sine filter cubicle.

The location and dimensions of the busbars for either case are visible in the dimensional drawings delivered with the drive, as well as the example dimension drawings in the manual.

■ Connection diagram



The recommended cable types are given in chapter Technical data.


■ Procedure




WARNING!

Obey the instructions in chapter . If you ignore them, injury or death, or damage to the equipment can occur.

1. Do the steps in section *Electrical safety precautions (page 27)* before you start the work.
2. Open the door of the common motor terminal or sine filter cubicle and remove the shrouding.
3. Lead the cables into the cubicle. Make the 360° earthing arrangement at the cable entry as shown.




4. Cut the cables to suitable length. Strip the cables and conductors.
5. Twist the cable screens into bundles and connect the bundles to the PE busbar in the cubicle.
6. Connect any separate ground conductors/cables to the PE busbar in the cubicle.
7. Connect the phase conductors to the output terminals. Use the torques specified under [Tightening torques \(page 115\)](#).
8. Refit any shrouding removed earlier and close the cubicle doors.
9. At the motor, connect the cables according to instructions from the motor manufacturer. Pay special attention to the phase order. For minimum radio-frequency interference, ground the cable shield 360 degrees at the lead-through of the motor terminal box, or ground the cable by twisting the shield so that the flattened shield is wider than 1/5 of its length.



Connecting a PC

A PC (with eg, the Drive composer PC tool) can be connected as follows:

1. Connect an ACx-AP-x control panel to the unit either
 - by inserting the control panel into the panel holder or platform (if present), or
 - by using an Ethernet (eg, Cat 5e) networking cable.
2. Remove the USB connector cover on the front of the control panel.
3. Connect an USB cable (Type A to Type Mini-B) between the USB connector on the control panel (3a) and a free USB port on the PC (3b).
4. The panel will display an indication whenever the connection is active.



5. See the documentation of the PC tool for setup instructions.



Panel bus (Control of several units from one control panel)

One control panel (or PC) can be used to control several drives (or inverter units, supply units etc.) by constructing a panel bus. This is done by daisy-chaining the panel connections of the drives. Some drives have the necessary (twin) panel connectors in the control panel holder; those that do not require the installation of an FDPI-02 module (available separately). For further information, see the hardware description and *FDPI-02 diagnostics and panel interface user's manual* (3AUA0000113618 [English]).

The maximum allowed length of the cable chain is 100 m (328 ft).

1. Connect the panel to one drive using an Ethernet (for example Cat 5e) cable.
 - Use Menu - Settings - Edit texts - Drive to give a descriptive name to the drive
 - Use parameter 49.01* to assign the drive with a unique node ID number
 - Set other parameters in group 49* if necessary
 - Use parameter 49.06* to validate any changes.

*The parameter group is 149 with supply (line-side), brake or DC/DC converter units.

Repeat the above for each drive.



2. With the panel connected to one unit, link the units using Ethernet cables.
3. Switch on the bus termination on the drive that is farthest from the control panel in the chain.
 - With drives that have the panel mounted on the front cover, move the terminating switch into the outer position.
 - With an FDPI-02 module, move termination switch S2 into the TERMINATED position.

Make sure that bus termination is off on all other drives.





4. On the control panel, switch on the panel bus functionality (Options - Select drive - Panel bus). The drive to be controlled can now be selected from the list under Options - Select drive.

If a PC is connected to the control panel, the drives on the panel bus are automatically displayed in the Drive composer tool.

With twin connectors in the control panel holder:



With FDPI-02 modules:



Installing option modules

■ Mechanical installation of I/O extension, fieldbus adapter and pulse encoder interface modules

See hardware description for the available slots for each module. Install the option modules as follows:



WARNING!

Obey the instructions in chapter . If you ignore them, injury or death, or damage to the equipment can occur.

1. Stop the drive and do the steps in section *Electrical safety precautions (page 27)* before you start the work.
2. Open the door of the auxiliary control cubicle (ACU).
3. Remove the shrouding at the top of the cubicle.
4. Locate the inverter control unit (A41).
5. Insert the module carefully into its position on the control unit.
6. Fasten the mounting screw.

Note:

The screw secures and grounds the module. It is essential for fulfilling the EMC requirements and for proper operation of the module.

■ Installation of an FSO-xx safety functions module onto BCU




WARNING!

Read the safety instructions given in *Safety instructions for ACS880 liquid-cooled multidrive cabinets and modules (3AXD50000048633 [English])*. If you ignore them, injury or death, or damage to the equipment can occur.

This procedure describes the installation of an FSO-xx safety functions module onto the BCU control unit. (The FSO-xx can alternatively be installed beside the control unit, which is the standard with factory-installed FSO-xx modules. For instructions, see the FSO-xx manual.)

1. Stop the inverter unit and do the steps in section *Electrical safety precautions (page 27)* before you start the work.
 2. The FSO-xx comes with alternative bottom plates for mounting on different units. For mounting on the BCU, the mounting points should be located at the long edges of the module as shown. Replace the bottom plate of the FSO-xx if necessary.
 3. Fasten the FSO-xx onto slot 3 of the BCU control unit [A41] with four screws.
-




4. Tighten the FSO-xx electronics grounding screw.

Note:

The screw tightens the connections and grounds the module. It is essential for fulfilling the EMC requirements and for proper operation of the module.

5. Connect the FSO-xx data cable between FSO-xx connector X110 and BCU-x2 connector X12.
6. To complete the installation, refer to the instructions in the User's manual delivered with the FSO-xx.



■ **Wiring of optional modules**

See the appropriate optional module manual for specific installation and wiring instructions.





Installation checklist of the drive

Contents of this chapter

This chapter contains a checklist of the mechanical and electrical installation of the drive.

Checklist

Examine the mechanical and electrical installation of the drive before start-up. Go through the checklist together with another person.



WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

If you are not a qualified electrician, do not do installation or maintenance work.



WARNING!

Stop the drive and do the steps in section *Electrical safety precautions (page 27)* before you start the work.

Make sure that ...	<input checked="" type="checkbox"/>
The ambient operating conditions meet the drive ambient conditions specification, and enclosure rating (IP code or UL enclosure type).	<input type="checkbox"/>
The supply voltage matches the nominal input voltage of the drive. See the type designation label.	<input type="checkbox"/>
The drive cabinet has been attached to floor, and if necessary due to vibration etc, also by its top to the wall or roof.	<input type="checkbox"/>
<u>If the drive is connected to a network other than a symetrically grounded TN-S system:</u> Check the compatibility. See the electrical installation instructions in the supply unit manual.	<input type="checkbox"/>
There is an adequately sized protective earth (ground) conductor between the drive and the switchboard, the conductor has been connected to appropriate terminal, and the terminal has been tightened to the proper torque. Proper grounding has also been measured according to the regulations.	<input type="checkbox"/>

48 Installation checklist of the drive

Make sure that ...	<input checked="" type="checkbox"/>
The input power cable has been connected to the appropriate terminals, the phase order is right, and the terminals have been tightened to the proper torque.	<input type="checkbox"/>
There is an adequately sized protective earth (ground) conductor between the motor and the drive, and the conductor has been connected to appropriate terminal, and the terminal has been tightened to the proper torque. (Pull on the conductors to check.). Proper grounding has also been measured according to the regulations.	<input type="checkbox"/>
The motor cable has been connected to the appropriate terminals, the phase order is right, and the terminals have been tightened to the proper torque.	<input type="checkbox"/>
The motor cable has been routed away from other cables.	<input type="checkbox"/>
No power factor compensation capacitors have been connected to the motor cable.	<input type="checkbox"/>
The control cables have been connected to the appropriate terminals, and the terminals have been tightened to the proper torque.	<input type="checkbox"/>
The voltage setting of the auxiliary voltage transformers (if any) is correct. See the electrical installation instructions.	<input type="checkbox"/>
<u>If a drive bypass connection will be used:</u> The direct-on-line contactor of the motor and the drive output contactor are either mechanically and/or electrically interlocked, ie, cannot be closed simultaneously. A thermal overload device must be used for protection when bypassing the drive. Refer to local codes and regulations.	<input type="checkbox"/>
There are no tools, foreign objects or dust from drilling inside the drive.	<input type="checkbox"/>
Cover(s) of the motor connection box are in place. Cabinet shrouds are in place and doors are closed.	<input type="checkbox"/>
The motor and the driven equipment are ready for start.	<input type="checkbox"/>
The coolant connections between cubicles (if any) and to the cooling circuit are tight.	<input type="checkbox"/>
<u>If the drive is equipped with a cooling unit:</u> Refer to the cooling unit documentation for specific tasks.	<input type="checkbox"/>

5

Start-up

Contents of this chapter

This chapter contains the start-up procedure of the drive.

Start-up procedure

The tasks which are needed in certain cases only are marked with underlining, and option codes are given in brackets. Default device designations (if any) are given in brackets after the name, for example “main switch-disconnector [Q1]”. The same device designations are also used in the circuit diagrams.

These instructions cannot and do not cover all possible start-up tasks of a customized drive. Always refer to the delivery-specific circuit diagrams when proceeding with the start-up.



WARNING!

Only qualified electricians are allowed to do the work described in this chapter.

Note:

For certain options (such as functional safety options +Q950, +Q951, +Q952, +Q957, +Q963, +Q964, +Q978, +Q979), additional start-up instructions are given in their separate manuals.


Action	<input checked="" type="checkbox"/>
Safety	
 WARNING! Obey the safety instructions during the start-up procedure. See chapter <i>The Safe torque off function</i> (page 77).	<input type="checkbox"/>
Checks/Settings with no voltage connected	
Ensure that the disconnecter of the supply transformer is locked to the off (0) position, ie. no voltage is, and cannot be connected to the drive inadvertently.	<input type="checkbox"/>

Action	<input checked="" type="checkbox"/>
Check that the main switch-disconnector (Q1.1) is switched off, or main breaker (Q1) racked out.	<input type="checkbox"/>
Check the mechanical and electrical installation of the drive. See Installation checklist of the drive (page 47) .	<input type="checkbox"/>
Check the settings of breakers/switches in the auxiliary circuits. See the circuit diagrams delivered with the drive.	<input type="checkbox"/>
Check that the auxiliary voltage selector [X59] on the front plate of the inverter modules is set according to actual auxiliary voltage (230 or 115 V AC).	<input type="checkbox"/>
Disconnect any unfinished or uninspected auxiliary voltage (115/230 V AC) cables that lead from the terminal blocks to the outside of the equipment.	<input type="checkbox"/>
Check that both channels of the Safe torque off circuit connected to the STO inputs of both the supply control unit [A51] and the inverter control unit [A41] are closed. Refer to the wiring diagrams delivered with the drive.	<input type="checkbox"/>
If the Safe torque off functionality is used, check that the STO OUT output on the inverter control unit (A41) is chained to the STO inputs of all inverter modules. If the Safe torque off functionality is not used, check that the STO input on all inverter modules is correctly wired to +24 V and ground.	<input type="checkbox"/>
Drives with Pt100 relays (option +(n)L506): <ul style="list-style-type: none"> • Check the connections against the circuit diagrams of the delivery. • Set the alarm and trip levels of the Pt100 relays. Set the alarm and trip levels of the Pt100 relay as low as possible based on the operating temperature and test results of the machine. The trip level can be set, for example, 10 °C higher than what the temperature of the machine is at maximal load in the maximum environmental temperature. We recommend to set the operating temperatures of the relay, typically for example, as follows: <ul style="list-style-type: none"> • 120...140 °C when only tripping is in use • alarm 120...140 °C and trip 130...150 °C when both alarm and tripping are used. 	<input type="checkbox"/>
Powering up the auxiliary circuit of the drive	
Make sure that it is safe to connect voltage. Ensure that <ul style="list-style-type: none"> • nobody is working on the drive or circuits that have been wired from outside into the drive cabinet • the cover of the motor terminal box is in place. 	<input type="checkbox"/>
Close the circuit breakers and/or fuse disconnectors supplying the auxiliary voltage circuits.	<input type="checkbox"/>
Close the cabinet doors.	<input type="checkbox"/>
Close the main breaker of the supply transformer.	<input type="checkbox"/>
Switch on the auxiliary voltage [Q21].	<input type="checkbox"/>
Setting up the supply unit parameters	
Check the voltage range setting in parameter <i>195.01 Supply voltage</i> . If you need more information on the use of the control panel, see the <i>ACX-AP-x Assistant control panels user's manual</i> (3AUA0000085685 [English]).	<input type="checkbox"/>
Setting up the inverter unit parameters, and performing the first start	
Set up the inverter control program. See the appropriate start-up guide and/or firmware manual. There is a separate start-up guide only for some control programs.	<input type="checkbox"/>
Check that parameter <i>95.09 Switch fuse controller</i> is set to <i>Disabled</i> .	<input type="checkbox"/>
Drives with an fieldbus adapter module (optional): Set the fieldbus parameters. Activate the appropriate assistant (if present) in the control program, or see the user's manual of the fieldbus adapter module, and the drive firmware manual. Check that the communication works between the drive and the PLC.	<input type="checkbox"/>
Drives with an encoder interface module (optional): Set the encoder parameters. Activate the appropriate assistant (if present) in the control program, or see the user's manual of the encoder interface module, and the drive firmware manual.	<input type="checkbox"/>
Powering up the main circuit of the drive	



Action	<input checked="" type="checkbox"/>
Close the main switch-disconnector [Q1.1] or main breaker [Q1].	<input type="checkbox"/>
<p>Note:</p> <p>Do not use excessive force. The main switch-disconnector (or main breaker) can only be closed when</p> <ul style="list-style-type: none"> • the main input terminals [L1, L2, L3] are powered, and • auxiliary voltage is switched on [Q21], and 	
Turn the operating switch (S21) to the ON (1) position to activate the run enable signal. Depending on control source settings, this may also close the main contactor (if present). If a main contactor is present and does not close, refer to the circuit diagrams delivered by the drive as well as the appropriate firmware manuals.	<input type="checkbox"/>
On-load checks	
Start the motor to perform the ID run.	<input type="checkbox"/>
Check that the cooling fans rotate freely in the right direction, and the air flows upwards.	<input type="checkbox"/>
Check that the motor starts, stops and follows the speed reference in the correct direction when controlled with the control panel.	<input type="checkbox"/>
Check that the motor starts, stops and follows the speed reference in the correct direction when controlled through the customer-specific I/O or fieldbus.	<input type="checkbox"/>
<u>Drives in which the Safe torque off control circuit is in use:</u> Test and validate the operation of the Safe torque off function. See section Acceptance test procedure (page 85) .	<input type="checkbox"/>





6

Maintenance

Contents of this chapter

This chapter contains maintenance instructions.

Maintenance intervals

The table below shows the maintenance tasks which can be done by the end user. The complete maintenance schedule is available on the Internet (www.abb.com/driveservices). For more information, consult your local ABB Service representative (www.abb.com/searchchannels).

Maintenance task/object	Years from start-up													
	0	1	2	3	4	5	6	7	8	9	10	11	12	...
Coolant														
Checking coolant antifreeze concentration		P	P	P	P	P	P	P	P	P	P	P	P	P
Checking coolant quality			P		P		P		P		P		P	
Coolant draining and replacement							R						R	
ABB cooling unit (if present)	See ACS880-1007LC liquid cooling unit user's manual (3AXD50000129607 [English])													
Cooling fans														
Inverter module fan (230 V)										R				
Inverter module fan (115 V)							R						R	
Batteries														
Control panel battery										R				

Maintenance task/object	Years from start-up													
	0	1	2	3	4	5	6	7	8	9	10	11	12	...
Control unit battery							R						R	
Spare parts														
Spare parts		I	I	I	I	I	I	I	I	I	I	I	I	I
DC circuit capacitor reforming (spare inverter modules and spare capacitors)		P	P	P	P	P	P	P	P	P	P	P	P	P
Inspections														
Checking tightness of cable and busbar terminals. Tightening if needed.		I	I	I	I	I	I	I	I	I	I	I	I	I
Checking ambient conditions (dustiness, corrosion, temperature)		I	I	I	I	I	I	I	I	I	I	I	I	I
Checking coolant pipe connections		I	I	I	I	I	I	I	I	I	I	I	I	I
3AXD10000578918 F														

Symbols

- I Inspection** (visual inspection and maintenance action if needed)
- P Performance** of on/off-site work (commissioning, tests, measurements or other work)
- R Replacement**

Maintenance and component replacement intervals are based on the assumption that the equipment is operated within the specified ratings and ambient conditions. ABB recommends annual drive inspections to ensure the highest reliability and optimum performance.

Note:

Long term operation near the specified maximum ratings or ambient conditions may require shorter maintenance intervals for certain components. Consult your local ABB Service representative for additional maintenance recommendations.

Retightening the power connections



WARNING!

Read the safety instructions given in *Safety instructions for ACS880 liquid-cooled multidrive cabinets and modules* (3AXD50000048633 [English]). If you ignore them, injury or death, or damage to the equipment can occur.

1. Repeat the steps described in section *Electrical safety precautions* (page 27).
2. Check the tightness of the cable connections. Use the tightening torques given in the technical data.

Fans

The lifespan of the cooling fans of the drive depends on the running time, ambient temperature and dust concentration. See the firmware manual for the actual signal which indicates the running time of the cooling fan. Reset the running time signal after fan replacement.


Replacement fans are available from ABB. Do not use other than ABB specified spare parts.

■ Inverter module fan replacement

**WARNING!**

Wear protective gloves and long sleeves. Some parts have sharp edges.

1. Repeat the steps described in section [Electrical safety precautions \(page 27\)](#).
2. Remove any shrouding in front of the cooling fan.
3. Disconnect the fan wiring.
4. Undo the two retaining screws (a).
5. Pull the fan outwards to separate it from the heat exchanger housing.
6. Install new fan in reverse order. Align the guide pins (b) at the rear of the fan cowling with the slots (c) in the module bottom guide, then reinstall the retaining screws (a).




■ Replacing the common motor terminal cubicle fan



WARNING!

Wear protective gloves and long sleeves. Some parts have sharp edges.

1. Stop the drive and do the steps in section *Electrical safety precautions (page 27)* before you start the work.
2. Remove any shrouding in front of the cooling fan.
3. Disconnect the fan wiring.
4. Undo the fastening screws.
5. Pull the fan housing up and out.
6. Install a new fan in reverse order to the above.



Inverter modules

■ Replacing a frame R8i inverter module

**WARNING!**

Obey the safety instructions given in *Safety instructions for ACS880 liquid-cooled multidrive cabinets and modules* (3AXD50000048633 [English]). If you ignore the safety instructions, injury or death, or damage to the equipment can occur.

If you are not a qualified electrician, do not do installation or maintenance work.

**WARNING!**


Make sure that the replacement module has exactly the same type code as the old module.

**WARNING!**

Beware of hot coolant. Do not work on the liquid cooling system until the pressure is lowered down by stopping the pumps and draining the coolant. High-pressure warm coolant (6 bar, max. 50 °C) is present in the internal cooling circuit when it is in operation.


**WARNING!**

Use the required personal protective equipment. Wear protective gloves and long sleeves. Some parts have sharp edges.




Removing the module


1. Repeat the steps described in section Electrical safety precautions.
2. Remove the shrouding in front of the module.
3. Undo the locking screws of the swing-out frame (if present) and open it.
4. Unplug the wiring from the module and move it aside. Use cable ties to keep the wiring out of the way.
5. Remove the L-shaped DC busbars at the top of the module. Make note of the orientation of the screws as well as the order of the washers.




6. Close the inlet valve (a) and outlet valve (located on the right-hand side of the cubicle) valves. Lead the drain hoses (b, on both sides of the cubicle) into a suitable container. Open the drain valves (c, on both sides of the cubicle). This will drain all modules in the cubicle.



7. After the module has drained, disconnect the piping from the module.



8. Remove the module retaining screws at the top and the bottom of the module.



9. Pull the module carefully out onto a table or other platform. Keep the module secured to a hoist or equivalent to prevent the module from falling. For information on using the lifting device, see *Converter module lifting device for drive cabinets hardware manual* (3AXD50000210268 [English]).

Reinstalling the module

1. Push the module carefully into its bay.
2. Fasten the retaining screws at the top and the bottom of the module.
3. Reinstall the DC busbars at the top of the module.
4. Reconnect the coolant pipes to the module.
5. Reconnect the control wiring to the module.
6. Fill up the cooling system. For instructions, see section *Filling up and bleeding the internal cooling circuit*.
7. Close the swing-out frame (if present). Reinstall all shrouds removed earlier.
8. If the Safe torque off function is in use, perform an acceptance test as described under *Start-up including acceptance test (page 85)*.

Capacitors

The DC circuit of the power modules of the drive contain several electrolytic capacitors. Their lifespan depends on the operating time of the drive, loading and ambient temperature. Capacitor life can be prolonged by lowering the ambient temperature.

Capacitor failure is usually followed by damage to the unit and an input cable fuse failure, or a fault trip. Contact ABB if capacitor failure is suspected. Replacements are available from ABB. Do not use other than ABB specified spare parts. Contact an ABB service representative for spare parts and repair services.

■ Reforming the capacitors

The capacitors must be reformed if the drive has not been powered (either in storage or unused) for a year or more. The manufacturing date is on the type designation label. For information on reforming the capacitors, see *Converter module capacitor reforming instructions* (3BFE64059629 [English]) in the ABB Library (<https://library.abb.com/en>).

If the drive module has been stored for one to three years, turn on the mains power for 30 minutes without load, then continue as usual.

If the drive module has been stored for less than a year, continue as usual.

DC fuse replacement



WARNING!

Read the safety instructions given in *Safety instructions for ACS880 multidrive cabinets and modules* (3AUA0000102301 [English]). If you ignore them, injury or death, or damage to the equipment can occur.




WARNING!

Read the safety instructions given in *Safety instructions for ACS880 liquid-cooled multidrive cabinets and modules* (3AXD50000048633 [English]). If you ignore them, injury or death, or damage to the equipment can occur.

1. Stop the drive and do the steps in section *Electrical safety precautions (page 27)* before you start the work.
 2. Open the door of the cubicle in which the fuses are.
 3. Remove the shrouding from in front of the fuses.
 4. Slacken the nuts of the headless screws of the fuses so that you can slide out the fuse blocks. Make note of the order of the washers on the screws.
 5. Remove the screws, nuts and washers from the old fuses and attach them to the new fuses. Make sure to keep the washers in the original order.
 6. Insert the new fuses into their slots in the cubicle. Pre-tighten the nuts first by hand or by applying a torque of no more than 5 N·m (3.7 lbf-ft).
 7. Tighten the nuts to torque as follows:
 - Cooper-Bussmann fuses: 50 N·m (37 lbf-ft)
 - Mersen (Ferraz-Shawmut): 46 N·m (34 lbf-ft)
 - Other: Refer to the fuse manufacturer's instructions.
-

8. Reinstall the shroud and close the door.



Control panel

For detailed information on the control panel, see *ACx-AP-x assistant control panels user's manual* (3AUA0000085685 [English]).

■ **Cleaning the control panel**

Use a soft damp cloth to clean the control panel. Avoid harsh cleaners which could scratch the display window.

■ **Replacing the control panel battery**

For instructions on how to replace the control panel battery, see the separate *ACx-AP-x assistant control panels user's manual* document (3AUA0000085685 [English]).

Control units

■ BCU control unit types

There are three variants of the BCU control unit used in ACS880 drives: BCU-02, BCU-12 and BCU-22. These have a different number of converter module connections (2, 7 and 12 respectively) but are otherwise identical. The three BCU types are interchangeable as long as the number of connections is sufficient. For example, the BCU-22 can be used as a direct replacement for both BCU-02 and BCU-12.

■ Replacing the memory unit


After replacing a control unit, you can retain the existing parameter settings by transferring the memory unit from the defective control unit to the new control unit.



WARNING!

Do not remove or insert the memory unit when the control unit is powered.

1. Stop the drive and do the steps in section [Electrical safety precautions \(page 27\)](#) before you start the work.
2. Make sure that the control unit is not powered.
3. Undo the fastening screw and pull the memory unit out.
4. Install a memory unit in reverse order.




■ Replacing the BCU control unit battery

Replace the real-time clock battery if the BATT OK LED is not illuminated when the control unit is powered.

1. Stop the drive and do the steps in section [Electrical safety precautions \(page 27\)](#) before you start the work.
2. Undo the fastening screw and remove the battery
3. Replace the battery with a new BR2032 battery.
4. Dispose of the old battery according to local disposal rules or applicable laws.

5. Set the real-time clock.





Control units of the drive

Contents of this chapter

This chapter


- describes the connections of the control unit(s) used in the drive,
- contains the specifications of the inputs and outputs of the control unit(s).

General


The BCU-x2 control unit is used with frame size R8i and multiples. The BCU-x2 consists of a BCON-12 control board (and a BIOC-01 I/O connector board and power supply board) built in a metal housing. The control unit is connected to the inverter module(s) by fiber optic cables.

In this manual, the name “BCU-x2” represents the control unit types BCU-02, BCU-12 and BCU-22. These have a different number of power module connections (2, 7 and 12 respectively) but are otherwise similar.

BCU-x2 control unit layout and connections



	Description
I/O	I/O terminals (see following diagram)
SLOT 1	I/O extension, encoder interface or fieldbus adapter module connection. (This is the sole location for an FDPI-02 diagnostics and panel interface.)
SLOT 2	I/O extension, encoder interface or fieldbus adapter module connection
SLOT 3	I/O extension, encoder interface, fieldbus adapter or FSO-xx safety functions module connection
SLOT 4	RDCO-0x DDCS communication option module connection
X205	Memory unit connection
BATTERY	Holder for real-time clock battery (BR2032)
A11	Mode selector for analog input A11 (I = current, U = voltage)
A12	Mode selector for analog input A12 (I = current, U = voltage)
D2D TERM	Termination switch for drive-to-drive link (D2D)
DICOM= DIOGND	Ground selection. Determines whether DICOM is separated from DIOGND (ie. the common reference for the digital inputs floats). See the ground isolation diagram.
7-segment display	
Multicharacter indications are displayed as repeated sequences of characters	
	("U" is indicated briefly before "o".) Control program running
	Control program startup in progress
	(Flashing) Firmware cannot be started. Memory unit missing or corrupted
	Firmware download from PC to control unit in progress
	At power-up, the display may show short indications of eg. "1", "2", "b" or "U". These are normal indications immediately after power-up. If the display ends up showing any other value than those described, it indicates a hardware failure.




	Description
XAI	Analog inputs
XAO	Analog outputs
XDI	Digital inputs, Digital input interlock (DIIL)
XDIO	Digital input/outputs
XD2D	Drive-to-drive link
XD24	+24 V output (for digital inputs)
XETH	Ethernet port – Not in use
XPOW	External power input
XRO1	Relay output RO1
XRO2	Relay output RO2
XRO3	Relay output RO3
XSTO	Safe torque off connection (input signals)
XSTO OUT	Safe torque off connection (to inverter modules)
X12	(On the opposite side) Connection for FSO-xx safety functions module (optional)
X13	Control panel / PC connection
X485	Not in use
V1T/V1R, V2T/V2R	Fiber optic connection to modules 1 and 2 (VxT = transmitter, VxR = receiver)
V3T/V3R ... V7T/V7R	Fiber optic connection to modules 3...7 (BCU-12/22 only) (VxT = transmitter, VxR = receiver)
V8T/V8R ... V12T/V12R	Fiber optic connection to modules 8...12 (BCU-22 only) (VxT = transmitter, VxR = receiver)
SD CARD	Data logger memory card for inverter module communication
BATT OK	Real-time clock battery voltage is higher than 2.8 V. If the LED is off when the control unit is powered, replace the battery.
FAULT	The control program has generated a fault. See the firmware manual of the supply/inverter unit.
PWR OK	Internal voltage supply is OK
WRITE	Writing to memory card in progress. Do not remove the memory card.

Default I/O diagram of the inverter control unit (A41)

The diagram below shows the default I/O connections on the inverter control unit (A41), and describes the use of the connections in the inverter unit. Under normal circumstances, the factory-made wiring should not be changed.

The wire size accepted by all screw terminals (for both stranded and solid wire) is 0.5 ... 2.5 mm² (24...12 AWG). The torque is 0.5 N·m (5 lbf·in).



Notes:


- 1) See section [The XD2D connector \(page 72\)](#).
- 2) See chapter [The Safe torque off function \(page 77\)](#).
- 3) 0 = Acceleration/deceleration ramps defined by parameters 23.12/23.13 in use. 1 = Acceleration/deceleration ramps defined by parameters 23.14/23.15 in use.
- 4) Constant speed 1 is defined by parameter 22.26.
- 5) See section [DIIL input \(page 72\)](#).
- 6) Total load capacity of these outputs is 4.8 W (200 mA at 24 V) minus the power taken by DIO1 and DIO2.
- 7) Determines whether DICOM is separated from DIOGND (ie. common reference for digital inputs floats; in practice, selects whether the digital inputs are used in current sinking or sourcing mode). See also [BCU-x2 ground isolation diagram \(page 76\)](#).
DICOM=DIOGND ON: DICOM connected to DIOGND. OFF: DICOM and DIOGND separate.
- 8) Current [0(4)...20 mA, $R_{in} = 100 \text{ ohm}$] or voltage [0(2)...10 V, $R_{in} > 200 \text{ kohm}$] input selected by switch AI1. Change of setting requires reboot of control unit.
- 9) Current [0(4)...20 mA, $R_{in} = 100 \text{ ohm}$] or voltage [0(2)...10 V, $R_{in} > 200 \text{ kohm}$] input selected by switch AI2. Change of setting requires reboot of control unit.

External power supply for the control unit (XPOW)

The control unit is powered from a 24 V DC, 2 A supply through terminal block XPOW. With a type BCU control unit, a second supply can be connected to the same terminal block for redundancy.

DI6 as a PTC sensor input


A PTC sensor can be connected to this input for motor temperature measurement as follows. The sensor can alternatively be connected to FEN-xx encoder interface module. At the sensor end of the cable, leave the shields unconnected or ground them indirectly via a high-frequency capacitor with a few nanofarads, for example 3.3 nF / 630 V AC. The shield can also be grounded directly at both ends if they are in the same ground line with no significant voltage drop between the end points. See the firmware manual of the inverter unit for parameter settings.

**WARNING!**

As the inputs pictured above are not insulated according to IEC 60664, the connection of the motor temperature sensor requires double or reinforced insulation between motor live parts and the sensor. If the assembly does not fulfill the requirement, the I/O board terminals must be protected against contact and must not be connected to other equipment or the temperature sensor must be isolated from the I/O terminals.

AI1 or AI2 as a Pt100, Pt1000, PTC or KTY84 sensor input

Three Pt100/Pt1000 sensors or one KTY84 sensor for motor temperature measurement can be connected between an analog input and output as shown below. (Alternatively, you can connect the KTY to an FIO-11 or FAIO-01 analog I/O extension module or FEN-xx encoder interface module.) At the sensor end of the cable, leave the shields unconnected or ground them indirectly via a high-frequency capacitor with a few nanofarads, for example 3.3 nF / 630 V. The shield can also be grounded directly at both ends if they are in the same ground line with no significant voltage drop between the end points.



1) Set the input type to voltage with the appropriate switch or jumper on the inverter control unit. Make the corresponding setting in the inverter unit control program in parameter group **12 Standard AI**.

2) Select the excitation mode in parameter group **13 Standard AO** of inverter unit control program.



WARNING!

As the inputs pictured above are not insulated according to IEC/EN 60664, the connection of the motor temperature sensor requires double or reinforced insulation between motor live parts and the sensor. If the assembly does not fulfill the requirement, the I/O board terminals must be protected against contact and must not be connected to other equipment or the temperature sensor must be isolated from the I/O terminals.

DIIL input

The DIIL input is used for the connection of safety circuits. The input is parametrized to stop the unit when the input signal is lost.

Note:

This input is NOT SIL or PI certified.

The XD2D connector

The XD2D connector provides an RS-485 connection that can be used for

- basic master/follower communication with one master drive and multiple followers,
- fieldbus control through the embedded fieldbus interface (EFB), or

- drive-to-drive (D2D) communication implemented by application programming.


See the firmware manual of the drive for the related parameter settings.

Enable bus termination on the units at the ends of the drive-to-drive link. Disable bus termination on the intermediate units.

Use shielded twisted-pair cable with a twisted pair for data and a wire or another pair for signal ground (nominal impedance 100 to 165 ohm, for example Belden 9842) for the wiring. For best immunity, ABB recommends high quality cable. Keep the cable as short as possible. Avoid unnecessary loops and parallel runs near power cables such as motor cables.

The following diagram shows the wiring between control units.

BCU-x2



Safe torque off (XSTO, XSTO OUT)

See chapter [The Safe torque off function \(page 77\)](#).

Note:

The XSTO input only acts as a true Safe torque off input on the inverter control unit. De-energizing the IN1 and/or IN2 terminals of other units (supply, DC/DC converter, or brake unit) will stop the unit but not constitute a true safety function.


FSO-xx safety functions module connection (X12)

See the user manual of the FSO-xx module. Note that the FSO-xx safety functions module is not in use in supply (or DC/DC converter or brake) units.

SDHC memory card slot


The BCU-x2 has an on-board data logger that collects real-time data from the power modules to help fault tracing and analysis. The data is stored onto the SDHC memory card inserted into the SD CARD slot and can be analyzed by ABB service personnel.

Connector data

Power supply (XPOW)	<p>Connector pitch 5 mm, wire size 2.5 mm² 24 V (±10%) DC, 2 A External power input. Two supplies can be connected for redundancy.</p>
Relay outputs RO1...RO3 (XRO1...XRO3)	<p>Connector pitch 5 mm, wire size 2.5 mm² 250 V AC / 30 V DC, 2 A Protected by varistors</p>
+24 V output (XD24:2 and XD24:4)	<p>Connector pitch 5 mm, wire size 2.5 mm² Total load capacity of these outputs is 4.8 W (200 mA / 24 V) minus the power taken by DIO1 and DIO2.</p>
Digital inputs DI1...DI6 (XDI:1...XDI:6)	<p>Connector pitch 5 mm, wire size 2.5 mm² 24 V logic levels: "0" < 5 V, "1" > 15 V R_{in}: 2.0 kohm Input type: NPN/PNP (DI1...DI5), NPN (DI6) Hardware filtering: 0.04 ms, digital filtering up to 8 ms DI6 (XDI:6) can alternatively be used as an input for a PTC sensor. "0" > 4 kohm, "1" < 1.5 kohm. I_{max}: 15 mA (DI1...DI5), 5 mA (DI6)</p>
Start interlock input DIIL (XDI:7)	<p>Connector pitch 5 mm, wire size 2.5 mm² 24 V logic levels: "0" < 5 V, "1" > 15 V R_{in}: 2.0 kohm Input type: NPN/PNP Hardware filtering: 0.04 ms, digital filtering up to 8 ms</p>
<p>Digital inputs/outputs DIO1 and DIO2 (XDIO:1 and XDIO:2) Input/output mode selection by parameters. DIO1 can be configured as a frequency input (0...16 kHz with hardware filtering of 4 microseconds) for 24 V level square wave signal (sinusoidal or other wave form cannot be used). DIO2 can be configured as a 24 V level square wave frequency output. See the firmware manual of the supply/inverter unit, parameter group 111/11.</p>	<p>Connector pitch 5 mm, wire size 2.5 mm² <u>As inputs:</u> 24 V logic levels: "0" < 5 V, "1" > 15 V. R_{in}: 2.0 kohm. Filtering: 1 ms. <u>As outputs:</u> Total output current from +24VD is limited to 200 mA</p> 
Reference voltage for analog inputs +VREF and -VREF (XAI:1 and XAI:2)	<p>Connector pitch 5 mm, wire size 2.5 mm² 10 V ±1% and -10 V ±1%, R_{load} 1...10 kohm Maximum output current: 10 mA</p>

Analog inputs AI1 and AI2 (XAI:4 ... XAI:7). Current/voltage input mode selection by switches	Connector pitch 5 mm, wire size 2.5 mm ² Current input: -20...20 mA, $R_{in} = 100 \text{ ohm}$ Voltage input: -10...10 V, $R_{in} > 200 \text{ kohm}$ Differential inputs, common mode range $\pm 30 \text{ V}$ Sampling interval per channel: 0.25 ms Hardware filtering: 0.25 ms, adjustable digital filtering up to 8 ms Resolution: 11 bit + sign bit Inaccuracy: 1% of full scale range
Analog outputs AO1 and AO2 (XAO)	Connector pitch 5 mm, wire size 2.5 mm ² 0...20 mA, $R_{load} < 500 \text{ ohm}$ Frequency range: 0...500 Hz Resolution: 11 bit + sign bit Inaccuracy: 2% of full scale range
XD2D connector	Connector pitch 5 mm, wire size 2.5 mm ² Physical layer: RS-485 Termination by switch
RS-485 connection (X485)	Connector pitch 5 mm, wire size 2.5 mm ² Physical layer: RS-485
Safe torque off connection (XSTO)	Connector pitch 5 mm, wire size 2.5 mm ² Input voltage range: -3...30 V DC Logic levels: "0" < 5 V, "1" > 17 V. Note: For the unit to start, both connections must be "1". This applies to all control units (including drive, inverter, supply, brake, DC/DC converter etc. control units), but true Safe torque off functionality is only achieved through the XSTO connector of the drive/inverter control unit. Current consumption: 66 mA (continuous) per STO channel per R8i module EMC (immunity) according to IEC 61326-3-1 See also chapter The Safe torque off function (page 77) .
Safe torque off output (XSTO OUT)	Connector pitch 5 mm, wire size 2.5 mm ² To STO connector of inverter module.
Control panel connection (X13)	Connector: RJ-45 Cable length < 3 m
Ethernet connection (XETH)	Connector: RJ-45 This connection is not supported by the firmware.
SDHC memory card slot (SD CARD)	Memory card type: SDHC Maximum memory size: 4 GB
The terminals of the control unit fulfill the Protective Extra Low Voltage (PELV) requirements. The PELV requirements of a relay output are not fulfilled if a voltage higher than 48 V is connected to the relay output.	

■ BCU-x2 ground isolation diagram



*Ground selector (DICOM=DIOGND) settings

DICOM=DIOGND: ON
All digital inputs share a common ground (DICOM connected to DIOGND). This is the default setting.
DICOM=DIOGND: OFF
Ground of digital inputs DI1...DI5 and DIIL (DICOM) is isolated from DIO signal ground (DIOGND). Isolation voltage 50 V.



The Safe torque off function

Contents of this chapter

This chapter describes the Safe torque off (STO) function of the inverter and gives instructions for its use.

Description

The Safe torque off function can be used, for example, to as the final actuator device of safety circuits that stop the inverter in case of danger (such as an emergency stop circuit). Another typical application is a prevention of unexpected start-up function that enables short-time maintenance operations like cleaning or work on non-electrical parts of the machinery without switching off the power supply to the inverter.

When activated, the Safe torque off function disables the control voltage of the power semiconductors of the inverter output stage (A, see the diagrams below), thus preventing the inverter from generating the torque required to rotate the motor. If the motor is running when Safe torque off is activated, it coasts to a stop.

The Safe torque off function has a redundant architecture, that is, both channels must be used in the safety function implementation. The safety data given in this manual is calculated for redundant use, and does not apply if both channels are not used.

The Safe torque off function complies with these standards:

Standard	Name
IEC 60204-1:2016 EN 60204-1:2006 + A1:2009 + AC:2010	<i>Safety of machinery – Electrical equipment of machines – Part 1: General requirements</i>
IEC 61000-6-7:2014	<i>Electromagnetic compatibility (EMC) – Part 6-7: Generic standards – Immunity requirements for equipment intended to perform functions in a safety-related system (functional safety) in industrial locations</i>

Standard	Name
IEC 61326-3-1:2017	<i>Electrical equipment for measurement, control and laboratory use – EMC requirements – Part 3-1: Immunity requirements for safety-related systems and for equipment intended to perform safety-related functions (functional safety) – General industrial applications</i>
IEC 61508-1:2010	<i>Functional safety of electrical/electronic/programmable electronic safety-related systems – Part 1: General requirements</i>
IEC 61508-2:2010	<i>Functional safety of electrical/electronic/programmable electronic safety-related systems – Part 2: Requirements for electrical/electronic/programmable electronic safety-related systems</i>
IEC 61511-1:2016	<i>Functional safety – Safety instrumented systems for the process industry sector</i>
IEC 61800-5-2:2016 EN 61800-5-2:2007	<i>Adjustable speed electrical power drive systems – Part 5-2: Safety requirements – Functional</i>
IEC 62061:2005 + A1:2012 + A2:2015 EN 62061:2005 + AC:2010 + A1:2013 + A2:2015	<i>Safety of machinery – Functional safety of safety-related electrical, electronic and programmable electronic control systems</i>
EN ISO 13849-1:2015	<i>Safety of machinery – Safety-related parts of control systems – Part 1: General principles for design</i>
EN ISO 13849-2:2012	<i>Safety of machinery – Safety-related parts of control systems – Part 2: Validation</i>

The function also corresponds to Prevention of unexpected start-up as specified by EN ISO 14118:2018 (ISO 14118:2017), and Uncontrolled stop (stop category 0) as specified in EN/IEC 60204-1.

■ Compliance with the European Machinery Directive

See *Electrical planning instructions for ACS880 liquid-cooled multidrive cabinets and modules* (3AXD50000048634 [English]).

Wiring

For the electrical specifications of the STO connection, see the technical data of the control unit.

■ Activation switch

In the wiring diagrams, the activation switch has the designation [K]. This represents a component such as a manually operated switch, an emergency stop push button switch, or the contacts of a safety relay or safety PLC.

- In case a manually operated activation switch is used, the switch must be of a type that can be locked out to the open position.
- The contacts of the switch or relay must open/close within 200 ms of each other.
- An FSO-xx safety functions module or and FPTC-0x thermistor protection module can also be used. For more information, see the module documentation.

■ Cable types and lengths

- Double-shielded twisted-pair cable is recommended.
- Maximum cable lengths:
 - 300 m (1000 ft) between activation switch [K] and inverter control unit
 - 60 m (200 ft) between multiple drives or inverter units
 - 60 m (200 ft) between external power supply and first control unit
 - 30 m (100 ft) between BCU control unit and last inverter module in the chain.

Note:

A short-circuit in the wiring between the switch and an STO terminal causes a dangerous fault. Therefore, it is recommended to use a safety relay (including wiring diagnostics) or a wiring method (shield grounding, channel separation) which reduces or eliminates the risk caused by the short-circuit.

Note:

The voltage at the STO input terminals of the control unit (or frame R8i inverter module) must be at least 17 V DC to be interpreted as "1".


The pulse tolerance of the input channels is 1 ms.

■ Grounding of protective shields

- Ground the shield in the cabling between the activation switch and the control unit at the control unit only.
 - Ground the shield in the cabling between two control units at one control unit only.
 - Do not ground the shield in the cabling between BCU and R8i module, or between R8i modules.
-


■ Dual-channel connection with internal power supply

Frame R8i and multiples



1	Inverter control unit
2	Inverter module(s)
3	To remaining inverter modules
K	Activation switch

■ Single-channel connection of activation switch




Note:

- Both STO inputs (IN1, IN2) must be connected to the activation switch. Otherwise, no SIL/PL classification is given.
- Pay special attention to avoiding any potential failure modes for the wiring. For example, use shielded cable. For measures for fault exclusion of wiring, see eg. EN ISO 13849-2:2012, table D.4.


1	Inverter unit
2	Control unit
K	Activation switch

■ Multiple drives

Internal power supply



External power supply



Operation principle

1. The Safe torque off activates (the activation switch is opened, or safety relay contacts open).
2. The STO inputs of the inverter control unit de-energize.
3. The control unit cuts off the control voltage from the output IGBTs.
4. The control program generates an indication as defined by parameter 31.22 (refer to the firmware manual of the inverter).

The parameter selects which indications are given when one or both STO signals are switched off or lost. The indications also depend on whether the inverter is running or stopped when this occurs.

Note:

This parameter does not affect the operation of the STO function itself. The STO function will operate regardless of the setting of this parameter: a running drive will stop upon removal of one or both STO signals, and will not start until both STO signals are restored and all faults reset.

Note:

The loss of only one STO signal always generates a fault as it is interpreted as a malfunction of STO hardware or wiring.

5. The motor coasts to a stop (if running). The inverter cannot restart while the activation switch or safety relay contacts are open. After the contacts close, a reset may be needed (depending on the setting of parameter 31.22). A new start command is required to start the inverter.
-

Start-up including acceptance test

To ensure the safe operation of a safety function, validation is required. The final assembler of the machine must validate the function by performing an acceptance test. The acceptance test must be performed

- at initial start-up of the safety function
- after any changes related to the safety function (circuit boards, wiring, components, settings, etc.)
- after any maintenance work related to the safety function.

■ Competence

The acceptance test of the safety function must be carried out by a competent person with adequate expertise and knowledge of the safety function as well as functional safety, as required by IEC 61508-1 clause 6. The test procedures and report must be documented and signed by this person.

■ Acceptance test reports

Signed acceptance test reports must be stored in the logbook of the machine. The report shall include documentation of start-up activities and test results, references to failure reports and resolution of failures. Any new acceptance tests performed due to changes or maintenance shall be logged into the logbook.

■ Acceptance test procedure

After wiring the Safe torque off function, validate its operation as follows.

Note:

If the drive is equipped with safety option +L536, +L537, +Q950, +Q951, +Q952, +Q957, +Q963, +Q964, +Q978 or +Q979, do the procedure shown in the documentation of the option.

Note:

All inverter modules of the inverter unit must be powered and connected to the STO circuit during the acceptance test.

Action	<input checked="" type="checkbox"/>
 WARNING! Follow the safety instructions. If you ignore them, injury or death, or damage to the equipment can occur.	<input type="checkbox"/>
Ensure that the inverter can be run and stopped freely during start-up.	<input type="checkbox"/>
Stop the inverter (if running), switch the input power off and isolate the inverter from the power line using a disconnecter.	<input type="checkbox"/>
Check the STO circuit connections against the wiring diagram.	<input type="checkbox"/>
Close the disconnecter and switch the power on.	<input type="checkbox"/>

86 The Safe torque off function

<p>Action</p>	<input checked="" type="checkbox"/>
<p>Test the operation of the STO function when the motor is stopped.</p> <ul style="list-style-type: none"> • Give a stop command for the inverter (if running) and wait until the motor shaft is at a standstill. <p>Ensure that the inverter operates as follows:</p> <ul style="list-style-type: none"> • Open the STO circuit. The inverter generates an indication if one is defined for the 'stopped' state in parameter 31.22 (see the firmware manual). • Give a start command to verify that the STO function blocks the inverter's operation. The inverter generates a warning. The motor should not start. • Close the STO circuit. • Reset any active faults. Restart the inverter and check that the motor runs normally. 	<input type="checkbox"/>
<p>Test the operation of the STO function when the motor is running.</p> <ul style="list-style-type: none"> • Start the inverter and ensure the motor is running. • Open the STO circuit. The motor should stop. The inverter generates an indication if one is defined for the 'running' state in parameter 31.22 (see the firmware manual). • Reset any active faults and try to start the inverter. • Ensure that the motor stays at a standstill and the inverter operates as described above in testing the operation when the motor is stopped. • Close the STO circuit. • Reset any active faults. Restart the inverter and check that the motor runs normally. 	<input type="checkbox"/>
<p>Test the operation of the failure detection of the inverter. The motor can be stopped or running.</p> <ul style="list-style-type: none"> • Open the 1st channel of the STO circuit (wire coming to IN1). If the motor was running, it should coast to a stop. The inverter generates a <i>FA81 Safe Torque Off 1 loss</i> fault indication (see the firmware manual). • Give a start command to verify that the STO function blocks the inverter's operation. The motor should not start. • Close the STO circuit. • Reset any active faults. Restart the inverter and check that the motor runs normally. • Open the 2nd channel of the STO circuit (wire coming to IN2). If the motor was running, it should coast to a stop. The inverter generates a <i>FA82 Safe Torque Off 2 loss</i> fault indication (see the firmware manual). • Give a start command to verify that the STO function blocks the inverter's operation. The motor should not start. • Close the STO circuit. • Reset any active faults. Restart the inverter and check that the motor runs normally. 	<input type="checkbox"/>
<p>Document and sign the acceptance test report which verifies that the safety function is safe and accepted for operation.</p>	<input type="checkbox"/>

Use

1. Open the activation switch, or activate the safety functionality that is wired to the STO connection.
2. The STO inputs on the inverter control unit de-energize, and the control unit cuts off the control voltage from the output IGBTs.
3. The control program generates an indication as defined by parameter 31.22 (refer to the firmware manual of the inverter).
4. The motor coasts to a stop (if running). The inverter will not restart while the activation switch or safety relay contacts are open.
5. Deactivate the STO by closing the activation switch, or resetting the safety functionality that is wired to the STO connection.
6. Reset any faults before restarting.



WARNING!

The Safe torque off function does not disconnect the voltage of the main and auxiliary circuits from the inverter. Therefore maintenance work on electrical parts of the inverter or the motor can only be carried out after isolating the inverter from the supply and all other voltage sources.



WARNING!

The Safe torque off functionality is only achieved through the XSTO connector of the inverter control unit (A41). True Safe torque off functionality is not achieved through the XSTO connectors of other control units (such as the supply control unit or the brake control unit).

The Safe torque off function is supported by any ACS880 inverter or drive control program. It is not supported by supply, DC/DC converter or brake firmware.



WARNING!

(With permanent magnet or synchronous reluctance [SynRM] motors only)

In case of a multiple IGBT power semiconductor failure, the inverter can produce an alignment torque which maximally rotates the motor shaft by $180/p$ degrees (with permanent magnet motors) or $180/2p$ degrees (with synchronous reluctance [SynRM] motors) regardless of the activation of the Safe torque off function. p denotes the number of pole pairs.

Notes:

- If a running inverter is stopped by using the Safe torque off function, the inverter will cut off the motor supply voltage and the motor will coast to a stop. If this causes danger or is not otherwise acceptable, stop the inverter and machinery using the appropriate stop mode before activating the Safe torque off function.
 - The Safe torque off function overrides all other functions of the inverter.
 - The Safe torque off function is ineffective against deliberate sabotage or misuse.
 - The Safe torque off function has been designed to reduce the recognized hazardous conditions. In spite of this, it is not always possible to eliminate all potential hazards. The assembler of the machine must inform the final user about the residual risks.
-

Maintenance

After the operation of the circuit is validated at start-up, the STO function shall be maintained by periodic proof testing. In high demand mode of operation, the maximum proof test interval is 20 years. In low demand mode of operation, the maximum proof test interval is 5 or 2 years; see section [Safety data \(page 90\)](#). It is assumed that all dangerous failures of the STO circuit are detected by the proof test. To perform the proof test, do the [Acceptance test procedure \(page 85\)](#).

Note:

See also the Recommendation of Use CNB/M/11.050 (published by the European co-ordination of Notified Bodies) concerning dual-channel safety-related systems with electromechanical outputs:

- When the safety integrity requirement for the safety function is SIL 3 or PL e (cat. 3 or 4), the proof test for the function must be performed at least every month.
- When the safety integrity requirement for the safety function is SIL 2 (HFT = 1) or PL d (cat. 3), the proof test for the function must be performed at least every 12 months.

The STO function of the drive does not contain any electromechanical components.

In addition to proof testing, it is a good practice to check the operation of the function when other maintenance procedures are carried out on the machinery.

Include the Safe torque off operation test described above in the routine maintenance program of the machinery that the inverter runs.

If any wiring or component change is needed after start up, or the parameters are restored, follow the test given in section [Acceptance test procedure \(page 85\)](#).

Use only spare parts approved by ABB.

Record all maintenance and proof test activities in the machine logbook.

■ Competence

The maintenance and proof test activities of the safety function must be carried out by a competent person with adequate expertise and knowledge of the safety function as well as functional safety, as required by IEC 61508-1 clause 6.

Fault tracing

The indications given during the normal operation of the Safe torque off function are selected by inverter control program parameter 31.22.

The diagnostics of the Safe torque off function cross-compare the status of the two STO channels. In case the channels are not in the same state, a fault reaction function is performed and the inverter trips on an “STO hardware failure” fault. An attempt to use the STO in a non-redundant manner, for example activating only one channel, will trigger the same reaction.

See the firmware manual of the inverter control program for the indications generated by the inverter, and for details on directing fault and warning indications to an output on the control unit for external diagnostics.

Any failures of the Safe torque off function must be reported to ABB.

Safety data

The safety data for the Safe torque off function is given below.

Note:

The safety data is calculated for redundant use, and does not apply if both STO channels are not used.

Frame size	SIL/ SILCL	PL	SFF (%)	PFH ($T_1 = 20$ a) (1/h)	PFD _{avg} ($T_1 = 2$ a)	PFD _{avg} ($T_1 = 5$ a)	MTTF _D (a)	DC (%)	Cat.	SC	HFT	CCF	T _M (a)
R8i	3	e	>99	5.0E-11	4.5E-07	1.1E-06	23970	≥90	3	3	1	80	20
2×R8i	3	e	>99	6.2E-11	5.5E-07	1.3E-06	16330	≥90	3	3	1	80	20
3×R8i	3	e	>99	7.3E-11	6.5E-07	1.6E-06	12390	≥90	3	3	1	80	20
4×R8i	3	e	>99	8.4E-11	7.6E-07	1.9E-06	9980	≥90	3	3	1	80	20
5×R8i	3	e	>99	9.5E-11	8.6E-07	2.1E-06	8360	≥90	3	3	1	80	20
6×R8i	3	e	>99	1.1E-10	9.6E-07	2.4E-06	7190	≥90	3	3	1	80	20
7×R8i	3	e	>99	1.2E-10	1.1E-06	2.6E-06	6310	≥90	3	3	1	80	20
8×R8i	3	e	>99	1.3E-10	1.2E-06	2.8E-06	5620	≥90	3	3	1	80	20

3AXD10000078136 F


- The following temperature profile is used in safety value calculations:
 - 670 on/off cycles per year with $\Delta T = 71.66$ °C
 - 1340 on/off cycles per year with $\Delta T = 61.66$ °C
 - 30 on/off cycles per year with $\Delta T = 10.0$ °C
 - 32 °C board temperature at 2.0% of time
 - 60 °C board temperature at 1.5% of time
 - 85 °C board temperature at 2.3% of time.
- The STO is a type B safety component as defined in IEC 61508-2.
- Relevant failure modes:
 - The STO trips spuriously (safe failure)
 - The STO does not activate when requested
 - A fault exclusion on the failure mode “short circuit on printed circuit board” has been made (EN 13849-2, table D.5). The analysis is based on an assumption that one failure occurs at one time. No accumulated failures have been analyzed.
- STO response times:
 - STO reaction time (shortest detectable break): 1 ms
 - STO response time: 2 ms (typical), 25 ms (maximum)
 - Fault detection time: Channels in different states for longer than 200 ms
 - Fault reaction time: Fault detection time + 10 ms
- Indication delays:
 - STO fault indication (parameter 31.22) delay: < 500 ms
 - STO warning indication (parameter 31.22) delay: < 1000 ms

■ Abbreviations

Abbr.	Reference	Description
Cat.	EN ISO 13849-1	Classification of the safety-related parts of a control system in respect of their resistance to faults and their subsequent behavior in the fault condition, and which is achieved by the structural arrangement of the parts, fault detection and/or by their reliability. The categories are: B, 1, 2, 3 and 4.
CCF	EN ISO 13849-1	Common cause failure (%)
DC	EN ISO 13849-1	Diagnostic coverage
HFT	IEC 61508	Hardware fault tolerance
MTTF _D	EN ISO 13849-1	Mean time to dangerous failure: (Total number of life units) / (Number of dangerous, undetected failures) during a particular measurement interval under stated conditions
PFD _{avg}	IEC 61508	Average probability of dangerous failure on demand, that is, mean unavailability of a safety-related system to perform the specified safety function when a demand occurs
PFH	IEC 61508	Average frequency of dangerous failures per hour, that is, average frequency of a dangerous failure of a safety related system to perform the specified safety function over a given period of time
PL	EN ISO 13849-1	Performance level. Levels a...e correspond to SIL
SC	IEC 61508	Systematic capability
SFF	IEC 61508	Safe failure fraction (%)
SIL	IEC 61508	Safety integrity level (1...3)
SILCL	IEC/EN 62061	Maximum SIL (level 1...3) that can be claimed for a safety function or subsystem
STO	IEC/EN 61800-5-2	Safe torque off
T ₁	IEC 61508-6	Proof test interval. T ₁ is a parameter used to define the probabilistic failure rate (PFH or PFD) for the safety function or subsystem. Performing a proof test at a maximum interval of T ₁ is required to keep the SIL capability valid. The same interval must be followed to keep the PL capability (EN ISO 13849) valid. See also section Maintenance.
T _M	EN ISO 13849-1	Mission time: the period of time covering the intended use of the safety function/device. After the mission time elapses, the safety device must be replaced. Note that any T _M values given cannot be regarded as a guarantee or warranty.

■ TÜV certificate

The TÜV certificate is available on the Internet at www.abb.com/drives/documents.



9

Internal cooling circuit

Contents of this chapter

The cooling system of a liquid-cooled drive consists of two circuits: the internal cooling circuit and the external cooling circuit. The internal cooling circuit covers the heat-generating electrical components of the drive and transfers the heat to the cooling unit. In the cooling unit, the heat is transferred to the external cooling circuit which is usually part of a larger external cooling system. This chapter deals with the internal cooling circuit.

Applicability

The information in this chapter is applicable to cabinet-built ACS880 liquid-cooled drives. Except where otherwise indicated, the information is also applicable to drives built out of ACS880 liquid-cooled multidrive modules.


Internal cooling system

Note: This section describes cabinet-built, liquid-cooled ACS880 drives. The information in this section can be used as guidelines for building a drive system out of ACS880 liquid-cooled modules.

Each cubicle has an inlet and an outlet manifold, fitted with a stop valve and a drain valve. The stop valves can be closed to isolate all modules in the cubicle from the main cooling circuit.

The following diagram shows the coolant pipe connections in a drive system consisting of a supply unit and an inverter unit.

94 Internal cooling circuit



The coolant used with ACS880 liquid-cooled drive systems is Antifrogen® L 25% or 50% water mixture. See [Coolant specification \(page 98\)](#).

Connection to a cooling unit

■ Connection to an ACS880-1007LC cooling unit

Refer to *ACS880-1007LC cooling unit user's manual* (3AXD50000129607 [English]).

■ Connection to a custom cooling unit

General requirements

Equip the system with an expansion tank to damp pressure rise due to volume changes when the temperature varies. Equip the system with a pump that provides a nominal flow and pressure. Keep the pressure within the limits specified in *Technical data (page 98)*. Install a pressure regulator to make sure that the maximum permissible operating pressure is not exceeded.

Install a bleed valve at the highest point of the cooling circuit, and a drain valve at the lowest point.

The materials that can be used are listed in *Cooling circuit materials (page 100)*.

Coolant temperature control

The temperature of the coolant in the internal cooling circuit must be kept within the limits specified in *Technical data (page 98)*. Note that the minimum temperature is dependent on ambient temperature and relative humidity.

Filling up and bleeding the internal cooling circuit

Both the drive and coolant must be at room temperature before filling up the cooling circuit.



WARNING!

Make sure that the maximum permissible operating pressure is not exceeded. When necessary regulate the pressure to appropriate level by draining excess coolant out of the system.



WARNING!

Bleeding of the cooling circuit is very important and has to be done with great care. Air bubbles in the cooling circuit may reduce or completely block coolant flow and lead to overheating. Let the air out of the cooling system while filling in coolant and, eg. after any power module replacements.

■ Drive line-ups with an ACS880-1007LC cooling unit

Follow the filling up and bleeding instructions in *ACS880-1007LC cooling unit user's manual* (3AXD50000129607 [English]).

■ Drive line-ups with a custom cooling unit

Note:

- In filling up the system, the drain valves in the line-up are used only to vent the air from the circuit so that it can be displaced by the coolant. The actual bleeding of the circuit must be done via an external bleed valve installed at the highest point of the cooling circuit. The most practical location for the valve is usually near or at the cooling unit.
- Observe the instructions given by the manufacturer of the cooling unit. Pay special attention to filling up and bleeding the pumps properly as they may be damaged if operated when dry.
- Draining coolant into the sewer system is not allowed.

1. Open the bleed valve at the cooling unit.
2. Open the inlet valve and the outlet-side drain valve of one cubicle. Keep the outlet valve and the inlet-side drain valve closed.
3. Attach a hose to the outlet-side drain valve and lead it into a suitable container.
4. Fill the circuit with coolant. For coolant specification, see [Coolant specification \(page 98\)](#).

Note: To minimize foaming, do not exceed the filling flow rate of 5 l/min (1.3 US gallon/min).

5. As the piping and modules in the cubicle fills up, coolant starts to flow from the hose. Let some coolant flow out, then close the drain valve.
 6. Close the inlet valve.
 7. Repeat steps 2 to 6 for all cubicles in the line-up.
 8. Open the inlet and outlet valves in all cubicles. Let any air remaining in the system out through the bleed valve at the cooling unit.
 9. Close the bleed valve at the cooling unit.
 10. Continue to fill in coolant until a base pressure of 100...150 kPa is achieved.
 11. Open the bleed valve of the pump to let out any air.
 12. Re-check the pressure and add coolant if necessary.
-

13. Start the coolant pump. Let any air remaining in the system out through the bleed valve at the cooling unit.
 14. After one to two minutes, stop the pump or block the coolant flow with a valve.
 15. Re-check the pressure and add coolant if necessary.
 16. Repeat steps 13 to 15 a few times until all air is let out of the cooling circuit. Listen for a humming sound and/or feel the piping for vibration to find out if there is still air left in the circuit.
-

Draining the internal cooling circuit

The modules in each cubicle can be drained through the drain valves without draining the whole internal cooling circuit.



WARNING!

Hot, pressurized coolant can be present in the cooling circuit. Do not work on the cooling circuit before the pressure is released by stopping the pumps and draining coolant.

1. Attach hoses to each drain valve in the cubicle to be drained. Lead the hoses into a suitable container. Make sure the ends of the hoses are not immersed in coolant at any point so that air can displace the coolant in the system.
2. Open the drain valves. Wait until all coolant has drained.

Note: Draining coolant into the sewer system is not allowed.

3. If required, dry the piping with compressed oil-free air of less than 6 bar.
4. If the drive is to be stored in temperatures below 0 °C (32 °F),
 - dry the cooling circuit with air,
 - fill the cooling circuit with coolant specified under *Coolant specification (page 98)*.
 - drain the cooling circuit again.

Maintenance intervals

As a general rule, the quality of the coolant should be checked at intervals of two years. This can be done by distributors of Antifrogen® L (see www.clariant.com) if a 250 milliliter sample is provided.

Technical data

■ Coolant specification

Coolant type

Antifrogen® L (by Clariant International Ltd, www.clariant.com) 25% or 50% water mixture, available from Clariant distributors and ABB Service representatives.

Antifrogen® L 25% mixture is usable in storage temperatures down to -16 °C (3.2 °F).

Antifrogen® L 50% mixture is usable in storage temperatures down to -40 °C (-40 °F).

Note that operation below 0 °C (32 °F) is not allowed regardless of the freezing point of the coolant.



WARNING!

The warranty does not cover damage occurring from use of improper coolant.


■ Temperature limits

Ambient temperature: See the technical data of the drive/unit.

Freeze protection: The freezing point of the coolant is determined by the concentration of heat transfer fluid in the mixture.

The higher the concentration of heat transfer fluid, the higher the viscosity of the coolant. This results in a higher pressure loss in the system. See *Pressure limits (page 100)*.


The nominal current ratings of drive system modules apply to an Antifrogen® L / water solution of 25/75% (volume). With the Antifrogen® L concentration between 25% and 50%, the drive output current must be derated by 1/3 percentage point per 1 p.p. increase in Antifrogen® L concentration. The drawing below shows the derating factor (*k*) in relation to Antifrogen® L concentration.



Incoming coolant temperature:

- 0...40 °C (32...104 °F): no drive output current derating required
- 40...45 °C (104...113 °F): drive output current must be derated by 2 percentage points per 1 °C (1.8 °F) temperature increase, as shown by curve (a).
- 45...50 °C (113...122 °F):
 - If components with a maximum operating temperature of 55 °C (131 °F) are installed in the same space as the drive modules, drive output current must be derated by 6 percentage points per 1 °C (1.8 °F) temperature increase, as shown by curve (c).
 - If there are no components with a maximum operating temperature of 55 °C (131 °F) installed in the same space as the drive modules, drive output current must be derated by 2 percentage points per 1 °C (1.8 °F) temperature increase, as shown by curve (b).

The drawing below shows the derating factor (*k*) in relation to coolant temperature.



Condensation is not allowed. The minimum coolant temperature to avoid condensation (at an atmospheric pressure of 1 bar) is shown below as a function of relative humidity (RH) and ambient temperature (T_{air}).

T_{air} (°C)	Min. $T_{coolant}$ (°C)				
	RH = 95%	RH = 80%	RH = 65%	RH = 50%	RH = 40%
5	4.3	1.9	-0.9	-4.5	-7.4

T_{air} (°C)	Min. T_{coolant} (°C)				
	RH = 95%	RH = 80%	RH = 65%	RH = 50%	RH = 40%
10	9.2	6.7	3.7	-0.1	-3.0
15	14.2	11.5	8.4	4.6	1.5
20	19.2	16.5	13.2	9.4	6.0
25	24.1	21.4	17.9	13.8	10.5
30	29.1	26.2	22.7	18.4	15.0
35	34.1	31.1	27.4	23.0	19.4
40	39.0	35.9	32.2	27.6	23.8
45	44.0	40.8	36.8	32.1	28.2
50	49.0	45.6	41.6	36.7	32.8
55	53.9	50.4	46.3	42.2	37.1
	= Not allowed as standard but the coolant temperature must be 0 °C (32 °F) or above.				
Example:	At an air temperature of 45 °C and relative humidity of 65% the coolant temperature may not be below +36.8 °C				

Maximum temperature rise: Depends on heat losses and mass flow. Typically 10 °C (18 °F) with nominal losses and flow.

■ Pressure limits

Base pressure: 100 ... 150 kPa (recommended); 200 kPa (maximum). "Base pressure" denotes the pressure of the system compared with the atmospheric pressure when the cooling circuit is filled with coolant.

Air counterpressure in the expansion tank: 40 kPa

Design pressure (PS): 600 kPa

Nominal pressure difference (between main in/out lines): 120 kPa with 25/75% (volume) coolant solution, 150 kPa with 50/50% (volume) coolant solution. This has to be taken into account when dimensioning the liquid cooling circuit.

Maximum pressure difference (between main in/out lines): 200 kPa

■ Coolant flow rate limits

The maximum coolant flow rate for all drive equipment is 1.3 × nominal. See the technical data chapter for nominal values.

■ Cooling circuit materials

Materials used in the internal cooling circuit are listed below. These are also the only materials that can be used in the external cooling circuit.

- stainless steel AISI 316L (UNS 31603)
- heavy gauge aluminum
- plastic materials such as PA, PEX and PTFE

Note: PVC hoses are not suitable for use with antifreeze.


- rubber gasketing NBR (nitrile rubber).



WARNING!

If connecting external piping to the internal cooling circuit, use only materials that are specified above. Copper, brass or bronze must not be used under any circumstances. Even minor dissolution of copper can cause copper precipitation on aluminum and subsequent galvanic corrosion. The liquid cooling system must not contain any zinc (eg. galvanized pipes).

If the plant incorporates normal iron pipes or cast iron accessories (eg. motor housings), a cooling unit with a heat exchanger (such as the ACS880-1007LC) must be used to separate the systems.



10

Technical data

Contents of this chapter

This chapter contains the technical specifications of the drive, for example, the ratings, fuse data, sizes and technical requirements, provisions for fulfilling the requirements for CE and other markings.

Ratings

ACS880-107LC-...	Input		Output									
	I_1	I_{max}	No-overload use				Light-overload use			Heavy-duty use		
			I_2	P_N		S_N	I_{Ld}	P_{Ld}		I_{Hd}	P_{Hd}	
	A	A	A	kW	hp	kVA	A	kW	hp	A	kW	hp
$U_N = 690\text{ V}$												
0390A-7	439	590	390	355	400	466	374	355	350	292	250	300
0430A-7	484	650	430	400	450	514	413	355	450	322	250	300
0480A-7	540	720	480	450	500	574	461	400	450	359	315	350
0530A-7	596	800	530	500	550	633	509	450	500	396	355	400
0600A-7	675	900	600	560	600	717	576	560	600	449	400	450
0670A-7	754	1010	670	630	700	801	643	630	700	501	450	500
0750A-7	844	1130	750	710	800	896	720	710	700	561	500	600
0850A-7	956	1280	850	800	900	1016	816	800	900	636	560	600
1030A-7	1159	1550	1030	1000	1000	1231	989	900	1000	770	710	800
1170A-7	1316	1760	1170	1100	1250	1398	1123	1100	1250	875	800	900
1310A-7	1474	1970	1310	1200	1250	1566	1258	1200	1250	980	900	1000
1470A-7	1654	2210	1470	1400	1500	1757	1411	1200	1500	1100	1000	1000
1660A-7	1868	2490	1660	1600	1750	1984	1594	1400	1750	1242	1200	1250
1940A-7	2183	2910	1940	1800	2000	2319	1862	1800	2000	1451	1400	1500
2180A-7	2453	3270	2180	2000		2605	2093	2000		1631	1400	1750
2470A-7	2779	3710	2470	2300		2952	2371	2300		1848	1800	2000
2880A-7	3240	4320	2880	2700		3442	2765	2700		2154	2000	
3260A-7	3668	4890	3260	3000		3896	3130	3000		2438	2300	
3580A-7	4028	5370	3580	3400		4279	3437	3200		2678	2600	
4050A-7	4556	6080	4050	3800		4840	3888	3800		3029	2800	
4840A-7	5445	7260	4840	4400		5784	4646	4400		3620	3500	
5650A-7	6356	8480	5650	5200		6752	5424	5200		4226	4000	
6460A-7	7268	9690	6460	6000		7720	6202	6000		4832	4700	

■ Definitions

U_N	Nominal AC supply voltage of drive system
I_1	Nominal rms input current
I_2	Nominal output current (available continuously with no over-loading)
P_N	Typical motor power in no-overload use The horsepower ratings are typical NEMA motor sizes at 460 V (ACS880-107LC-xxxxA-5) and 575 V (ACS880-107LC-xxxxA-7) respectively.
S_N	Apparent power in no-overload use
I_{Ld}	Continuous rms output current allowing 10% overload for 1 minute every 5 minutes
P_{Ld}	Typical motor power in light-overload use

I_{\max}	Maximum output current. Available for 10 seconds at start; otherwise as long as allowed by drive temperature.
I_{Hd}	Continuous rms output current allowing 50% overload for 1 minute every 5 minutes
P_{Hd}	Typical motor power in heavy-duty use


Note:

- The ratings apply at an ambient temperature of 40 °C (104 °F).
- The ratings apply at an ambient temperature of 45 °C (113 °F) and a coolant temperature of 40 °C (104 °F).
- To achieve the rated motor power given in the table, the rated current of the drive must be higher than or equal to the rated motor current.
- The DriveSize dimensioning tool available from ABB is recommended for selecting the drive, motor and gear combination.

■ **Derating**

Ambient temperature derating

In the temperature range +45...55 °C (+113...131 °F), the rated output current is derated by 0.5 percentage points for every added 1 °C (1.8 °F). The output current can be calculated by multiplying the current given in the rating table by the derating factor (k):



Coolant temperature derating

See section [Temperature limits \(page 98\)](#).

Antifreeze content derating

See section [Temperature limits \(page 98\)](#).

Altitude derating

At altitudes from 1000 to 4000 m (3281 to 13123 ft) above sea level, the output current derating is 1 percentage point for every added 100 m (328 ft). For example, the derating factor for 1500 m (4921 ft) is 0.95.

For a more accurate derating, use the DriveSize PC tool.

Switching frequency derating

In the switching frequency range of 3.0 to 7.5 kHz, the output current is derated by 8 percentage points per each kHz. For example, the derating factor for 5 kHz is 0.84.

Output frequency derating

Below the output frequency of 12 Hz, the output current is derated by 3.5 percentage points per each Hz. For example, the derating factor for 9 Hz is 0.895.

Above the output frequency of 150 Hz, the output current is derated by 1 percentage point per each 10 Hz. For example, the derating factor for 175 Hz is 0.975.

Inverter unit frame sizes and modules used

ACS880-107LC-...	Frame size	Module(s) used	
		Qty	Type
$U_N = 690 \text{ V}$			
0390A-7	R8i	1	ACS880-104LC-0390A-7+E205
0430A-7	R8i	1	ACS880-104LC-0430A-7+E205
0480A-7	R8i	1	ACS880-104LC-0480A-7+E205
0530A-7	R8i	1	ACS880-104LC-0530A-7+E205
0600A-7	R8i	1	ACS880-104LC-0600A-7+E205
0670A-7	R8i	1	ACS880-104LC-0670A-7+E205
0750A-7	R8i	1	ACS880-104LC-0750A-7+E205
0850A-7	R8i	1	ACS880-104LC-0850A-7+E205
1030A-7	2 × R8i	2	ACS880-104LC-0530A-7+E205
1170A-7	2 × R8i	2	ACS880-104LC-0600A-7+E205
1310A-7	2 × R8i	2	ACS880-104LC-0670A-7+E205
1470A-7	2 × R8i	2	ACS880-104LC-0750A-7+E205
1660A-7	2 × R8i	2	ACS880-104LC-0850A-7+E205
1940A-7	3 × R8i	3	ACS880-104LC-0670A-7+E205
2180A-7	3 × R8i	3	ACS880-104LC-0750A-7+E205
2470A-7	3 × R8i	3	ACS880-104LC-0850A-7+E205
2880A-7	4 × R8i	4	ACS880-104LC-0750A-7+E205
3260A-7	4 × R8i	4	ACS880-104LC-0850A-7+E205
3580A-7	5 × R8i	5	ACS880-104LC-0750A-7+E205
4050A-7	5 × R8i	5	ACS880-104LC-0850A-7+E205
4840A-7	6 × R8i	6	ACS880-104LC-0850A-7+E205
5650A-7	7 × R8i	7	ACS880-104LC-0850A-7+E205
6460A-7	8 × R8i	8	ACS880-104LC-0850A-7+E205

Cooling data and noise

ACS880-107LC-...	Coolant volume				Coolant flow		Heat dissipation		Noise dB(A)
	Modules		Cabinet piping		l/min	US gal/min	into coolant	into air*	
	l	US gal	l	US gal			kW	kW	
$U_N = 690\text{ V}$									
0390A-7	1.6	0.4	2.4	0.6	16	4.2	5.0	0.1	63
0430A-7	1.6	0.4	2.4	0.6	16	4.2	5.5	0.1	63
0480A-7	1.6	0.4	2.4	0.6	16	4.2	6.2	0.2	63
0530A-7	1.6	0.4	2.4	0.6	16	4.2	7.0	0.2	63
0600A-7	1.6	0.4	2.4	0.6	16	4.2	8.0	0.2	63
0670A-7	1.6	0.4	2.4	0.6	16	4.2	9.2	0.2	63
0750A-7	1.6	0.4	2.4	0.6	16	4.2	10.5	0.3	63
0850A-7	1.6	0.4	2.4	0.6	16	4.2	12.4	0.3	63
1030A-7	3.2	0.8	4.0	1.1	32	8.5	13.6	0.3	66
1170A-7	3.2	0.8	4.0	1.1	32	8.5	15.6	0.4	66
1310A-7	3.2	0.8	4.0	1.1	32	8.5	17.9	0.4	66
1470A-7	3.2	0.8	4.0	1.1	32	8.5	20.6	0.5	66
1660A-7	3.2	0.8	4.0	1.1	32	8.5	24.2	0.6	66
1940A-7	4.8	1.3	5.7	1.5	48	12.7	26.5	0.7	68
2180A-7	4.8	1.3	5.7	1.5	48	12.7	30.6	0.8	68
2470A-7	4.8	1.3	5.7	1.5	48	12.7	36.0	0.9	68
2880A-7	6.4	1.7	8.0	2.1	64	16.9	40.4	1.0	69
3260A-7	6.4	1.7	8.0	2.1	64	16.9	47.5	1.2	69
3580A-7	8.0	2.1	9.7	2.6	80	21.1	50.3	1.3	70
4050A-7	8.0	2.1	9.7	2.6	80	21.1	59.0	1.5	70
4840A-7	9.6	2.5	11.4	3.0	96	25.4	70.5	1.8	71
5650A-7	11.2	3.0	13.7	3.6	112	29.6	82.3	2.1	72
6460A-7	12.8	3.4	15.4	4.1	128	33.8	94.1	2.4	72
*ie. into air surrounding the cabinet									

DC fuses

The inverter unit has DC fuses at the input of each inverter module.

Notes:

- Fuses with higher current rating than the recommended ones must not be used.
- Fuses from other manufacturers can be used if they meet the ratings and the melting curve of the fuse does not exceed the melting curve of the fuse mentioned in the table.

ACS880-107LC-...	DC fuses at inverter module input				
	Qty	A	V	Manufacturer	Type
$U_N = 690 \text{ V}$					
0390A-7	2	800	1250	Bussmann	170M6546
0430A-7					
0480A-7	2	900	1100	Bussmann	170M6547
0530A-7	2	1000	1100	Bussmann	170M6548
0600A-7	2	1100	1000	Bussmann	170M6549
0670A-7	2	1250	1100	Bussmann	170M6500
0750A-7	2	1400	1100	Bussmann	170M6501
0850A-7					
1030A-7	4	1000	1100	Bussmann	170M6548
1170A-7	4	1100	1000	Bussmann	170M6549
1310A-7	4	1250	1100	Bussmann	170M6500
1470A-7	4	1400	1100	Bussmann	170M6501
1660A-7					
1940A-7	6	1250	1100	Bussmann	170M6500
2180A-7	6	1400	1100	Bussmann	170M6501
2470A-7	6				
2880A-7	8				
3260A-7	8				
3580A-7	10				
4050A-7	10				
4840A-7	12				
5650A-7	14				
6460A-7	16				

Dimensions and weights

See chapter [Dimensions \(page 119\)](#).

Free space requirements

The values are as required by cooling, maintenance and/or operation of the pressure relief (if present). Also obey the general mechanical installation instructions.

Front		Sides		Above	
mm	in.	mm	in.	mm	in.
150	5.90	0	0	250	9.85

Typical power cable sizes

The tables below give current carrying capacity (I_{Lmax}) for aluminum and copper PVC/XLPE insulated cables. A correction factor $K = 0.70$ is used. Time const is the temperature time constant of the cable.

The cable sizing is based on max. 9 cables laid on the cable trays side by side, three ladder type trays one on top of the other, ambient temperature 30 °C (EN 60204-1 and IEC 60364-5-52).

Aluminum cable		PVC insulation Conductor temperature 70°		XLPE insulation Conductor temperature 90°	
Size	∅ [mm]	I_{Lmax} [A]	Time const. [s]	I_{Lmax} [A]	Time const. [s]
3 × 35 + 10 Cu	26	67	736	84	669
3 × 50 + 15 Cu	29	82	959	102	874
3 × 70 + 21 Cu	32	105	1182	131	1079
3 × 95 + 29 Cu	38	128	1492	159	1376
3 × 120 + 41 Cu	41	148	1776	184	1637
3 × 150 + 41 Cu	44	171	2042	213	1881
3 × 185 + 57 Cu	49	196	2422	243	2237
3 × 240 + 72 Cu	54	231	2967	286	2740
3 × 300 + 88 Cu	58	267	3478	330	3229
2 × (3 × 70 + 21 Cu)	2 × 32	210	1182	262	1079
2 × (3 × 95 + 29 Cu)	2 × 38	256	1492	318	1376
2 × (3 × 120 + 41 Cu)	2 × 41	297	1776	368	1637
2 × (3 × 150 + 41 Cu)	2 × 44	343	2042	425	1881
2 × (3 × 185 + 57 Cu)	2 × 49	392	2422	486	2237
2 × (3 × 240 + 72 Cu)	2 × 54	462	2967	572	2740
2 × (3 × 300 + 88 Cu)	2 × 58	533	3478	659	3229
3 × (3 × 150 + 41 Cu)	3 × 44	514	2042	638	1881
3 × (3 × 185 + 57 Cu)	3 × 49	588	2422	728	2237
3 × (3 × 240 + 72 Cu)	3 × 54	693	2967	859	2740
3 × (3 × 300 + 88 Cu)	3 × 58	800	3478	989	3229
4 × (3 × 185 + 57 Cu)	4 × 49	784	2422	971	2237
4 × (3 × 240 + 72 Cu)	4 × 54	924	2967	1145	2740
4 × (3 × 300 + 88 Cu)	4 × 58	1067	3478	1319	3229
5 × (3 × 185 + 57 Cu)	5 × 49	980	2422	1214	2237
5 × (3 × 240 + 72 Cu)	5 × 54	1155	2967	1431	2740
5 × (3 × 300 + 88 Cu)	5 × 58	1333	3478	1648	3229
6 × (3 × 240 + 72 Cu)	6 × 54	1386	2967	1718	2740
6 × (3 × 300 + 88 Cu)	6 × 58	1600	3478	1978	3229
7 × (3 × 240 + 72 Cu)	7 × 54	1617	2967	2004	2740
7 × (3 × 300 + 88 Cu)	7 × 58	1867	3478	2308	3229
8 × (3 × 240 + 72 Cu)	8 × 54	1848	2967	2290	2740
8 × (3 × 300 + 88 Cu)	8 × 58	2133	3478	2637	3229
9 × (3 × 240 + 72 Cu)	9 × 54	2079	2967	2577	2740
9 × (3 × 300 + 88 Cu)	9 × 58	2400	3478	2967	3229
10 × (3 × 240 + 72 Cu)	10 × 54	2310	2967	2867	2740
10 × (3 × 300 + 88 Cu)	10 × 58	2667	3478	3297	3229

Copper cable		PVC insulation Conductor temperature 70°		XLPE insulation Conductor temperature 90°	
Size	∅ [mm]	I_{Lmax} [A]	Time const. [s]	I_{Lmax} [A]	Time const. [s]
3 × 1.5 + 1.5	13	13	85	16	67
3 × 2.5 + 2.5	14	18	121	23	88
(3 × 4 + 4)	16	24	175	30	133
3 × 6 + 6	18	30	251	38	186
3 × 10 + 10	21	42	359	53	268
3 × 16 + 16	23	56	514	70	391
3 × 25 + 16	24	71	791	89	598
3 × 35 + 16	26	88	1000	110	760
3 × 50 + 25	29	107	1308	134	990
3 × 70 + 35	32	137	1613	171	1230
3 × 95 + 50	38	167	2046	209	1551
3 × 120 + 70	41	193	2441	241	1859
3 × 150 + 70	44	223	2820	279	2139
3 × 185 + 95	50	255	3329	319	2525
3 × 240 + 120	55	301	4073	376	3099
3 × 300 + 150	58	348	4779	435	3636
2 × (3 × 70 + 35)	2 × 32	274	1613	342	1230
2 × (3 × 95 + 50)	2 × 38	334	2046	418	1551
2 × (3 × 120 + 70)	2 × 41	386	2441	482	1859
2 × (3 × 150 + 70)	2 × 44	446	2820	558	2139
2 × (3 × 185 + 95)	2 × 50	510	3329	638	2525
2 × (3 × 240 + 120)	2 × 55	602	4073	752	3099
2 × (3 × 300 + 150)	2 × 58	696	4779	869	3636
3 × (3 × 120 + 70)	3 × 41	579	2441	723	1859
3 × (3 × 150 + 70)	3 × 44	669	2820	837	2139
3 × (3 × 185 + 95)	3 × 50	765	3329	957	2525
3 × (3 × 240 + 120)	3 × 55	903	4073	1128	3099
3 × (3 × 300 + 150)	3 × 58	1044	4779	1304	3636
4 × (3 × 150 + 70)	4 × 44	892	2820	1116	2139
4 × (3 × 185 + 95)	4 × 50	1020	3329	1276	2525
4 × (3 × 240 + 120)	4 × 55	1204	4073	1504	3099
4 × (3 × 300 + 150)	4 × 58	1391	4779	1304	3636
5 × (3 × 185 + 95)	5 × 50	1275	3329	1595	2525
5 × (3 × 240 + 120)	5 × 55	1505	4073	1880	3099
5 × (3 × 300 + 150)	5 × 58	1739	4779	2173	3636
6 × (3 × 185 + 95)	6 × 50	1530	3329	1914	2525
6 × (3 × 240 + 120)	6 × 55	1806	4073	2256	3099
6 × (3 × 300 + 150)	6 × 58	2087	4779	2608	3636
7 × (3 × 240 + 120)	7 × 55	2107	4073	2632	3099
7 × (3 × 300 + 150)	7 × 58	2435	4779	3043	3636
8 × (3 × 240 + 120)	8 × 55	2408	4073	3008	3099
8 × (3 × 300 + 150)	8 × 58	2783	4779	3477	3636

Terminal and cable entry data for power cables

The locations and sizes of the cable entries and input power connections are shown by the dimension drawings delivered with the drive.

Drawings of output connections are shown in chapter [Dimensions \(page 119\)](#).

Terminal data for the inverter control unit

See chapter [Control units of the drive \(page 67\)](#).

Input power (DC) connection

Voltage (U_1)	ACS880-107LC-xxxxx-7: 709...976 V DC. This is indicated in the type designation label as typical input voltage levels (742/849/976 V DC).
Drive AC supply network type	TN (grounded) and IT (ungrounded) systems, corner-grounded systems up to 600 V AC

Motor (AC) connection

Motor types	Asynchronous AC induction motors, permanent magnet synchronous motors and AC induction servomotors, ABB synchronous reluctance (SynRM) motors
Voltage (U_2)	0 to AC supply voltage of drive, 3-phase symmetrical, U_{max} at field weakening point
Frequency (f_2)	0...500 Hz <ul style="list-style-type: none"> For higher operational output frequencies, please contact your local ABB representative. Operation outside the range of 12...150 Hz requires derating. See section Derating (page 105).
Current	See section Ratings.
Switching frequency	3 kHz (typical). The switching frequency can vary per frame and voltage. For exact values, contact your local ABB representative.
Maximum motor cable length	500 m (1640 ft) Note: Longer cables cause a motor voltage decrease which limits the available motor power. The decrease depends on the motor cable length and characteristics. Contact ABB for more information.
Output terminals	See chapter Dimensions.

Efficiency

98.5 ... 98.7% at nominal power level depending on drive type

Protection classes

Degrees of protection (IEC/EN 60529)	IP42 (standard), IP54 (option +B055)
Enclosure types (UL50)	UL Type 1 (standard), UL Type 12 (option +B055). For indoor use only.
Overvoltage category (IEC/EN 60664-1)	III, except for auxiliary power connections (fan, control, heating, lighting, cooling unit pump etc) which are category II.
Protective class (IEC/EN 61800-5-1)	I

Optical components

The specifications of the optic cable are as follows:

- Storage temperature: -55 ... +85 °C
- Installation temperature: -20 ... +70 °C
- Maximum short-term tensile force: 50 N
- Minimum short-term bend radius: 25 mm
- Minimum long-term bend radius: 35 mm
- Maximum long-term tensile load: 1 N
- Flexing: Max. 1000 cycles

ABB drive products in general utilize 5 and 10 MBd (megabaud) optical components from Avago Technologies' Versatile Link range. Note that the optical component type is not directly related to the actual communication speed.

Note:

The optical components (transmitter and receiver) on a fiber optic link must be of the same type.

Plastic optical fiber (POF) cables can be used with both 5 MBd and 10 MBd optical components. 10 MBd components also enable the use of Hard Clad Silica (HCS®) cables, which allow longer connection distances thanks to their lower attenuation. HCS® cables cannot be used with 5 MBd optical components.

The maximum lengths of fiber optic links for POF and HCS® cables are 20 and 200 meters respectively.

Ambient conditions

Environmental limits for the drive are given below. The drive is to be used in a heated, indoor, controlled environment.

	Operation installed for stationary use	Storage in the protective package	Transportation in the protective package
Installation site altitude	0...2000 m (0...6562 ft) above sea level. For altitudes over 2000 m, contact ABB. Output derated above 1000 m (3281 ft).	-	-
Air temperature	0 ... +45 °C (+32 ... +113 °F), no condensation allowed. Output derated in the range +45 ... +55 °C (+113 ... +131 °F).	-40 to +70 °C (-40 to +158 °F)	-40 to +70 °C (-40 to +158 °F)
Relative humidity	Max. 95%	Max. 95%	Max. 95%
	No condensation allowed. Maximum allowed relative humidity is 60% in the presence of corrosive gases.		
Contamination	IEC/EN 60721-3-3:2002: Classification of environmental conditions - Part 3-3: Classification of groups of environmental parameters and their severities - Stationary use of weather protected locations Chemical gases: Class 3C2 Solid particles: Class 3S2. No conductive dust allowed.	IEC 60721-3-1:1997 Chemical gases: Class 1C2 Solid particles: Class 1S3 (packing must support this, otherwise 1S2)	IEC 60721-3-2:1997 Chemical gases: Class 2C2 Solid particles: Class 2S2
Vibration IEC/EN 61800-5-1 IEC 60068-2-6:2007, EN 60068-2-6:2008 Environmental testing Part 2: Tests –Test Fc: Vibration (sinusoidal)	IEC/EN 60721-3-3:2002 10...57 Hz: max. 0.075 mm amplitude 57...150 Hz: 1 g Units with marine construction (option +C121): Max. 1 mm (0.04 in) (5 ... 13.2 Hz), max. 0.7 g (13.2 ... 100 Hz) sinusoidal	IEC/EN 60721-3-1:1997 10...57 Hz: max. 0.075 mm amplitude 57...150 Hz: 1 g	IEC/EN 60721-3-2:1997 2...9 Hz: max. 3.5 mm amplitude 9...200 Hz: 10 m/s ² (32.8 ft/s ²)
Shock IEC 60068-2-27:2008, EN 60068-2-27:2009 Environmental testing - Part 2-27: Tests - Test Ea and guidance: Shock	Not allowed	With packing max. 100 m/s ² (328 ft/s ²) 11 ms	With packing max. 100 m/s ² (328 ft/s ²) 11 ms

Materials

Cabinet	<ul style="list-style-type: none"> • Zinc coated steel sheet • Polyester thermosetting powder coating on visible surfaces, color RAL 7035 and RAL 9017
Busbars for user power connections	Tin-plated copper
Liquid cooling system	See Cooling circuit materials (page 100)
Fire safety of materials (IEC 60332-1)	Insulating materials and non-metallic items: mostly self-extinctive
Package	<p>Standard package:</p> <ul style="list-style-type: none"> • timber, polyethylene sheet (thickness 0.15 mm), stretch film (thickness 0.023 mm), PP tape, PET strap, sheet metal (steel) • for land and air transport when planned storage time is less than 2 months or when storage can be arranged in clean and dry conditions less than 6 months • can be used when products will not be exposed to corrosive atmosphere during transport or storage <p>Container package:</p> <ul style="list-style-type: none"> • timber, VCI sheet film (PE, thickness 0.10 mm), VCI stretch film (PE, thickness 0.04 mm), VCI emitter bags, PP tape, PET strap, sheet metal (steel) • for sea transport in containers • recommended for land and air transport when storage time prior to installation exceeds 6 months or storage is arranged in partially weather-protected conditions <p>Seaworthy package:</p> <ul style="list-style-type: none"> • timber, plywood, VCI sheet film (PE, thickness 0.10 mm), VCI stretch film (PE, thickness 0.04 mm), VCI emitter bags, PP tape, PET strap, sheet metal (steel) • for sea transport with or without containerization • for long storage periods in environments where roofed and humidity-controlled storage cannot be arranged <p>Cabinets are fastened to the pallet with screws and braced from the top end to the package walls to prevent swaying inside the package. Package elements are attached to each other with screws.</p>
Disposal	<p>The main parts of the drive can be recycled to preserve natural resources and energy. Product parts and materials should be dismantled and separated. Generally all metals, such as steel, aluminum, copper and its alloys, and precious metals can be recycled as material. Plastics, rubber, cardboard and other packaging material can be used in energy recovery. Printed circuit boards and large electrolytic capacitors need selective treatment according to IEC 62635 guidelines. To aid recycling, plastic parts are marked with an appropriate identification code. Contact your local ABB distributor for further information on environmental aspects and recycling instructions for professional recyclers. End of life treatment must follow international and local regulations.</p>

Applicable standards

See *Electrical planning instructions for ACS880 liquid-cooled multidrive cabinets and modules* (3AXD50000048634 [English]).

Markings

See *Electrical planning instructions for ACS880 liquid-cooled multidrive cabinets and modules* (3AXD50000048634 [English]).

Tightening torques

Unless a tightening torque is specified in the text, the following torques can be used.

■ Electrical connections

Size	Torque	Note
M3	0.5 N·m (4.4 lbf·in)	Strength class 4.6...8.8
M4	1 N·m (9 lbf·in)	Strength class 4.6...8.8
M5	4 N·m (35 lbf·in)	Strength class 8.8
M6	9 N·m (6.6 lbf·ft)	Strength class 8.8
M8	22 N·m (16 lbf·ft)	Strength class 8.8
M10	42 N·m (31 lbf·ft)	Strength class 8.8
M12	70 N·m (52 lbf·ft)	Strength class 8.8
M16	120 N·m (90 lbf·ft)	Strength class 8.8

■ Mechanical connections

Size	Max. torque	Note
M5	6 N·m (53 lbf·in)	Strength class 8.8
M6	10 N·m (7.4 lbf·ft)	Strength class 8.8
M8	24 N·m (17.7 lbf·ft)	Strength class 8.8

■ Insulation supports

Size	Max. torque	Note
M6	5 N·m (44 lbf·in)	Strength class 8.8
M8	9 N·m (6.6 lbf·ft)	Strength class 8.8
M10	18 N·m (13.3 lbf·ft)	Strength class 8.8
M12	31 N·m (23 lbf·ft)	Strength class 8.8

■ Cable lugs

Size	Max. torque	Note
M8	15 N·m (11 lbf·ft)	Strength class 8.8
M10	32 N·m (23.5 lbf·ft)	Strength class 8.8
M12	50 N·m (37 lbf·ft)	Strength class 8.8

Disclaimers

■ Generic disclaimer

The manufacturer shall have no obligation with respect to any product which (i) has been improperly repaired or altered; (ii) has been subjected to misuse, negligence or accident; (iii) has been used in a manner contrary to the manufacturer's instructions; or (iv) has failed as a result of ordinary wear and tear.

■ Cybersecurity disclaimer

This product is designed to be connected to and to communicate information and data via a network interface. It is Customer's sole responsibility to provide and continuously ensure a secure connection between the product and Customer network or any other network (as the case may be). Customer shall establish and maintain any appropriate measures (such as but not limited to the installation of firewalls, application of authentication measures, encryption of data, installation of anti-virus programs, etc) to protect the product, the network, its system and the interface against any kind of security breaches, unauthorized access, interference, intrusion, leakage and/or theft of data or information. ABB and its affiliates are not liable for damages and/or losses related to such security breaches, any unauthorized access, interference, intrusion, leakage and/or theft of data or information.



11

Dimensions

Cabinet line-up dimensions

The drive consists of cubicles built into a cabinet line-up. The table below shows the nominal width and weight of each inverter type. The dimensions are in millimeters (for inches, divide by 25.4).

Notes:

- The side panels at the left and right ends of the line-up increase the nominal line-up width by 30 millimeters (1.2”).
- The standard depth of the cabinet line-up is 644 mm (25.35”) excluding protruding equipment such as handles.
- The control electronics of the inverter unit must partly be housed outside the inverter module cubicles.
- The data given is preliminary. ABB reserves the right to modify the design at any time without notice. Consult ABB for up-to-date, drive-specific information.

The table is followed by selected dimension drawing examples.


■ Dimensions and weights

ACS880-107LC-...	Cubicle widths	Total unit width	Total unit weight	
	mm	mm	kg	lbs
$U_N = 690\text{ V}$				
0390A-7 0430A-7 0480A-7 0530A-7 0600A-7 0670A-7 0750A-7 0850A-7	300	300	300	660
1030A-7 1170A-7 1310A-7 1470A-7 1660A-7	500	500	430	950
1940A-7 2180A-7 2470A-7	700	700	600	1320
2880A-7 3260A-7	500 + 500	1000	860	1900
3580A-7 4050A-7	700 + 500	1200	1030	2270
4840A-7	700 + 700	1400	1200	2650
5650A-7	700 + 500 + 500	1700	1460	3220
6460A-7	700 + 700 + 500	1900	1720	3790


■ Dimension drawing examples

Cabinet height and depth

Non-marine, IP42, side view




Marine construction (option +C121), IP42, side view




Location and size of output terminals

■ Units without common motor terminal cubicle


Inverter module cubicle with one R8i module, bottom cable exit



Inverter module cubicle with two R8i modules, bottom cable exit




Inverter module cubicle with three R8i modules, bottom cable exit




■ Units with common motor terminal cubicle (+H359)


Cubicle width 300 mm, bottom cable exit




Cubicle width 300 mm, top cable exit




Cubicle width 400 mm, bottom cable exit




Cubicle width 400 mm, top cable exit



Cubicle width 600 mm, bottom cable exit



Cubicle width 600 mm, top cable exit



Further information

Product and service inquiries

Address any inquiries about the product to your local ABB representative, quoting the type designation and serial number of the unit in question. A listing of ABB sales, support and service contacts can be found by navigating to www.abb.com/searchchannels.

Product training

For information on ABB product training, navigate to new.abb.com/service/training.

Providing feedback on ABB manuals

Your comments on our manuals are welcome. Navigate to new.abb.com/drives/manuals-feedback-form.

Document library on the Internet

You can find manuals and other product documents in PDF format on the Internet at www.abb.com/drives/documents.



www.abb.com/drives



3AXD50000196111A